

DNP3 Device Profile

Based on DNP XML Schema version 2.08.00

Document Name: ControlEdge RTU and PLC DNP3 Outstation Device Profile RTDOC-X346-en-E

Document Description: This is a DNP3 device profile for the Honeywell ControlEdge RTU and PLC outstation device.

Revision History

Date	Time	Version	Reason for change	Edited by
2016-05-24		1	Initial revision for firmware version SC-UCMX01_120.1-21.0 of RTU2020 R120.	Honeywell with document ID RTDOC-X346-en-A
2018-04-04		2	Update product name as ControlEdge RTU; Update hardware version: SC-UCMX01 (ControlEdge 2020 Non-redundant controller); Kernel Board Version E, App Board Version A; SC-UCNN11 (ControlEdge 2020 Redundant controller); Kernel Board Version C Update build name as ControlEdge Builder; Update build version as RTU_120.1-21.0 or later.	Honeywell with document ID RTDOC-X346-en-B
2019-10-23		3	Update product name as ControlEdge RTU and PLC; Add hardware version: SC-UCMX02 (ControlEdge 2020 Non-redundant controller); Kernel Board Version B, App Board Version B; 900CP1-0200 (ControlEdge PLC CPM); Update build version as version 140 or later.	Honeywell with document ID RTDOC-X346-en-C
2021-08-26		4	Update the maximum number of objects allowed in a single control request for CROB, Analog Outputs and Data Sets.	Honeywell with document ID RTDOC-X346-en-D
2022-12-02		5	Updated the section 1.12 Security Parameters (1.12.1 – 1.12.17)	Honeywell International Sàrl

REFERENCE DEVICE:

1 Device Properties

This document is intended to be used for several purposes, including:

- Identifying the capabilities of a DNP3 device (Master Station or Outstation)
- Recording the settings of a specific instance of a device (parameter settings for a specific instance of the device in the user's total DNP3 estate)
- Matching user requirements to product capabilities when procuring a DNP3 device

The document is therefore structured to show, for each technical feature, the capabilities of the device (or capabilities required by the device when procuring).

It is also structured to show the current value (or setting) of each of the parameters that describe a specific instance of the device. This "current value" may also show a functional limitation of the device. For example when implementing secure authentication it is not required that all DNP3 devices accept aggressive mode requests during critical exchanges (see Device Profile 1.12.4), in which case a vendor would mark this current value as "No - does not accept aggressive mode requests".

Additionally, the current value may sometimes be used to show a value that a device can achieve because of hardware or software dependencies. An example of this is in section 1.6.8 of the Device Profile (Maximum error in the time that the Master issues freeze requests) where the value may well depend upon tolerances of hardware components and interactions between software tasks. When the Device Profile current value is used in this way the corresponding entry in the capabilities column is grayed-out. Users should note that if an entry in the capabilities column of the Device Profile is grayed-out then there may be information in the current value column that is pertinent to the device's capabilities.

Unless otherwise noted, multiple boxes in the second column below are selected for each parameter to indicate all capabilities supported or required. Parameters without checkboxes in the second column do not have capabilities and are included so that the current value may be shown in the third column.

The items listed in the capabilities column below may be configurable to any of the options selected, or set to a fixed value when the device was designed. Item 1.1.10 contains a list of abbreviations for the possible ways in which the configurable parameters may be set. Since some parameters may not be accessible by each of these methods supported, an abbreviation for the configuration method supported by each parameter is shown in the fourth column of the tables below.

If this document is used to show the current values, the third column should be filled in even if a fixed parameter is selected in the capabilities section ("NA" may be entered for parameters that are Not Applicable).

If the document is used to show the current values of parameters, then column 3 applies to a single connection between a master and an outstation.

1.1 DEVICE IDENTIFICATION	Capabilities	Current Value	If configurable list methods
<p>1.1.1 Device Function:</p> <p><i>Masters send DNP requests, while Outstations send DNP responses. If a single physical device can perform both functions a separate Device Profile Document must be provided for each function.</i></p>	<p><input type="radio"/> Master</p> <p><input checked="" type="radio"/> Outstation</p>	<p><input type="radio"/> Master</p> <p><input checked="" type="radio"/> Outstation</p>	
<p>1.1.2 Vendor Name:</p> <p><i>The name of the organization producing the device.</i></p> <p><i>Note: The current value of this outstation parameter is available remotely using protocol object Group 0 Variation 252.</i></p>		Honeywell	
<p>1.1.3 Device Name:</p> <p><i>The model and name of the device, sufficient to distinguish it from any other device from the same organization.</i></p> <p><i>Note: The current value of this outstation parameter is available remotely using protocol object Group 0 Variation 250.</i></p>		ControlEdge PLC & RTU. Model numbers: SC-UCMX01, ControlEdge 2020 Non-redundant controller; SC-UCNN11, ControlEdge 2020 Redundant controller; SC-UCMX02, ControlEdge 2020 Non-redundant controller; 900CP1-0200, ControlEdge 900 CPM	
<p>1.1.4 Device manufacturer's hardware version string:</p> <p><i>Note: The current value of this outstation parameter is available remotely using protocol object Group 0 Variation 243.</i></p>		SC-UCMX01: Kernel Board Version E, App Board Version A; SC-UCMX02: Kernel Board Version B, App Board Version B; SC-UCNN11: Kernel Board Version C; 900CP1-0200	
<p>1.1.5 Device manufacturer's software version string:</p> <p><i>Note: The current value of this outstation parameter is available remotely using protocol object Group 0 Variation 242.</i></p>		PLC/RTU_140 and later for SC-UCMX01 and SC-UCNN11; PLC/RTU_160 and later for SC-UCMX02 and 900CP1-0200	
<p>1.1.6 Device Profile Document Version Number:</p> <p><i>Version of the Device Profile Document is indicated by a whole number incremented with each new release. This should match the latest version shown in the Revision History at the beginning of this document.</i></p>		3	
<p>1.1.7 DNP Levels Supported for:</p> <p><i>Indicate each DNP3 Level to which the device conforms fully. For Masters, requests and responses can be indicated independently.</i></p>	<p>Outstations Only Requests and Responses</p> <p><input checked="" type="checkbox"/> None</p> <p><input checked="" type="checkbox"/> Level 1</p> <p><input checked="" type="checkbox"/> Level 2</p> <p><input checked="" type="checkbox"/> Level 3</p> <p><input checked="" type="checkbox"/> Level 4</p>	Level 4	

<p>1.1.8 Supported Function Blocks:</p>	<input checked="" type="checkbox"/> Self Address Support <input type="checkbox"/> Data Sets <input type="checkbox"/> File Transfer <input type="checkbox"/> Virtual Terminal <input type="checkbox"/> Mapping to IEC 61850 Object Models defined in a DNP3 XML file <input type="checkbox"/> Function code 31, activate configuration <input checked="" type="checkbox"/> Secure Authentication (if checked then see 1.12)	Self Address Secure Authentication																													
<p>1.1.9 Notable Additions:</p> <p><i>A brief description intended to quickly identify (for the reader) the most obvious features the device supports in addition to the Highest DNP Level Supported. The complete list of features is described in the Implementation Table.</i></p>																															
<p>1.1.10 Methods to set Configurable Parameters:</p>	<input type="checkbox"/> XML - Loaded via DNP3 File Transfer <input type="checkbox"/> XML - Loaded via other transport mechanism <input type="checkbox"/> Terminal - ASCII Terminal Command Line <input checked="" type="checkbox"/> Software - Vendor software named ControlEdge Builder140 or later <input type="checkbox"/> Proprietary file loaded via DNP3 File Transfer <input type="checkbox"/> Proprietary file loaded via other transport mechanism <input type="checkbox"/> Direct - Keypad on device front panel <input type="checkbox"/> Factory - Specified when device is ordered <input checked="" type="checkbox"/> Protocol - Set via DNP3 (e.g. assign class) <input type="checkbox"/> Other - explain:	Software Vendor software named ControlEdge Builder Version 140 or later Protocol																													
<p>1.1.11 DNP3 XML files available On-line:</p> <p><i>XML configuration file names that can be read or written through DNP3 File Transfer to a device.</i></p> <p><i>A device's currently running configuration is returned by DNP3 on-line XML file read from the device.</i></p> <p><i>DNP3 on-line XML file write to a device will update the device's configuration when the Activate Configuration (function code 31) is received.</i></p>	<table border="1"> <thead> <tr> <th>Rd</th> <th>Wr</th> <th>Filename</th> <th>Description of Contents</th> </tr> </thead> <tbody> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td>dnpDP.xml</td> <td>Complete Device Profile</td> </tr> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td>dnpDPCap.xml</td> <td>Device Profile Capabilities</td> </tr> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td>dnpDPCfg.xml</td> <td>Device Profile config values</td> </tr> </tbody> </table>	Rd	Wr	Filename	Description of Contents	<input type="checkbox"/>	<input type="checkbox"/>	dnpDP.xml	Complete Device Profile	<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCap.xml	Device Profile Capabilities	<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCfg.xml	Device Profile config values	<table border="1"> <thead> <tr> <th>Rd</th> <th>Wr</th> <th>Filename</th> </tr> </thead> <tbody> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td>dnpDP.xml</td> </tr> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td>dnpDPCap.xml</td> </tr> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td>dnpDPCfg.xml</td> </tr> </tbody> </table>	Rd	Wr	Filename	<input type="checkbox"/>	<input type="checkbox"/>	dnpDP.xml	<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCap.xml	<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCfg.xml	
Rd	Wr	Filename	Description of Contents																												
<input type="checkbox"/>	<input type="checkbox"/>	dnpDP.xml	Complete Device Profile																												
<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCap.xml	Device Profile Capabilities																												
<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCfg.xml	Device Profile config values																												
Rd	Wr	Filename																													
<input type="checkbox"/>	<input type="checkbox"/>	dnpDP.xml																													
<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCap.xml																													
<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCfg.xml																													
<p>1.1.12 External DNP3 XML files available Off-line:</p> <p><i>XML configuration file names that can be read or written from an external system, typically from a system that maintains the outstation configuration.</i></p> <p><i>External off-line XML file read permits an XML definition of a new configuration to be supplied from off-line configuration tools.</i></p> <p><i>External off-line XML file write permits an XML definition of a new configuration to be supplied to off-line configuration tools.</i></p>	<table border="1"> <thead> <tr> <th>Rd</th> <th>Wr</th> <th>Filename</th> <th>Description of Contents</th> </tr> </thead> <tbody> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td>dnpDP.xml</td> <td>Complete Device Profile</td> </tr> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td>dnpDPCap.xml</td> <td>Device Profile Capabilities</td> </tr> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td>dnpDPCfg.xml</td> <td>Device Profile config values</td> </tr> </tbody> </table>	Rd	Wr	Filename	Description of Contents	<input type="checkbox"/>	<input type="checkbox"/>	dnpDP.xml	Complete Device Profile	<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCap.xml	Device Profile Capabilities	<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCfg.xml	Device Profile config values	<table border="1"> <thead> <tr> <th>Rd</th> <th>Wr</th> <th>Filename</th> </tr> </thead> <tbody> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td>dnpDP.xml</td> </tr> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td>dnpDPCap.xml</td> </tr> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td>dnpDPCfg.xml</td> </tr> </tbody> </table>	Rd	Wr	Filename	<input type="checkbox"/>	<input type="checkbox"/>	dnpDP.xml	<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCap.xml	<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCfg.xml	
Rd	Wr	Filename	Description of Contents																												
<input type="checkbox"/>	<input type="checkbox"/>	dnpDP.xml	Complete Device Profile																												
<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCap.xml	Device Profile Capabilities																												
<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCfg.xml	Device Profile config values																												
Rd	Wr	Filename																													
<input type="checkbox"/>	<input type="checkbox"/>	dnpDP.xml																													
<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCap.xml																													
<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCfg.xml																													
<p>1.1.13 Connections Supported:</p>	<input type="checkbox"/> Serial (complete section 1.2) <input checked="" type="checkbox"/> IP Networking (complete section 1.3) <input type="checkbox"/> Other, explain	IP Networking																													

1.3 IP NETWORKING	Capabilities	Current Value	If configurable list methods
--------------------------	---------------------	----------------------	-------------------------------------

1.3.1 Port Name: <i>Name used to reference the communications port defined in this section.</i>		ETH1, ETH2	
1.3.2 Type of End Point:	<input type="checkbox"/> TCP Initiating (Master Only) <input checked="" type="checkbox"/> TCP Listening (Outstation Only) <input type="checkbox"/> TCP Dual (required for Masters) <input checked="" type="checkbox"/> UDP Datagram (required)	TCP Listening UDP Datagram	software ControlEdge Builder Vers 140 or later ----- --
1.3.3 IP Address of this Device:		*.*.*	software ControlEdge Builder Vers 140 or later ----- --
1.3.4 Subnet Mask:		*.*.*	software ControlEdge Builder Vers 140 or later ----- --
1.3.5 Gateway IP Address:		*.*.*	software ControlEdge Builder Vers 140 or later ----- --
1.3.6 Accepts TCP Connections or UDP Datagrams from:	<input checked="" type="checkbox"/> Allows all (show as *.*.* in 1.3.7) <input type="checkbox"/> Limits based on IP address <input type="checkbox"/> Limits based on list of IP addresses <input type="checkbox"/> Limits based on a wildcard IP address <input type="checkbox"/> Limits based on list of wildcard IP addresses <input type="checkbox"/> Other, explain	Allows all	
1.3.7 IP Address(es) from which TCP Connections or UDP Datagrams are accepted:		*.*.*	
1.3.8 TCP Listen Port Number: <i>If Outstation or dual end point Master, port number on which to listen for incoming TCP connect requests. Required to be configurable for Masters and recommended to be configurable for Outstations.</i>	<input type="checkbox"/> Not Applicable (Master w/o dual end point) <input type="checkbox"/> Fixed at 20,000 <input checked="" type="checkbox"/> Configurable, range 0 to 65535 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	20000	software ControlEdge Builder Vers 140 or later ----- --
1.3.9 TCP Listen Port Number of remote device: <i>If Master or dual end point Outstation, port number on remote device with which to initiate connection. Required to be configurable for Masters and recommended to be configurable for Outstations.</i>	<input checked="" type="checkbox"/> Not Applicable (Outstation w/o dual end point) <input type="checkbox"/> Fixed at 20,000 <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	Not Applicable	
1.3.10 TCP Keep-alive timer: <i>The time period for the keep-alive timer on active TCP connections.</i>	<input type="checkbox"/> Fixed at ms <input checked="" type="checkbox"/> Configurable, range 0 to 2147483647 ^{ms} <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe	5000 ms	software ControlEdge Builder Vers 140 or later ----- --
1.3.11 Local UDP port: <i>Local UDP port for sending and/or receiving UDP datagrams. Masters may let system choose an available port. Outstations must use one that is known by the Master.</i>	<input type="checkbox"/> Fixed at 20,000 <input checked="" type="checkbox"/> Configurable, range 0 to 65535 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Let system choose (Master only)	20000	software ControlEdge Builder Vers 140 or later ----- --

1.3.12 Destination UDP port for DNP3 Requests (Masters Only):	<input type="checkbox"/> Fixed at 20,000 <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe		
1.3.13 Destination UDP port for initial unsolicited null responses (UDP only Outstations): <i>The destination UDP port for sending initial unsolicited Null response.</i>	<input type="checkbox"/> None <input type="checkbox"/> Fixed at 20,000 <input checked="" type="checkbox"/> Configurable, range 0 to 65535 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	20000	software ControlEdge Builder Vers 140 or later ----- --
1.3.14 Destination UDP port for responses (UDP only Outstations): <i>The destination UDP port for sending all responses other than the initial unsolicited Null response.</i>	<input type="checkbox"/> None <input type="checkbox"/> Fixed at 20,000 <input checked="" type="checkbox"/> Configurable, range 0 to 65535 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Use source port number	20000	software ControlEdge Builder Vers 140 or later ----- --
1.3.15 Multiple outstation connections (Masters only): <i>Indicates whether multiple outstation connections are supported.</i>	<input type="checkbox"/> Supports multiple outstations (Masters only)		
1.3.16 Multiple master connections (Outstations only): <i>Indicates whether multiple master connections are supported and the method that can be used to establish connections.</i>	<input checked="" type="checkbox"/> Supports multiple masters (Outstations only) If supported, the following methods may be used: <input checked="" type="checkbox"/> Method 1 (based on IP address) - required <input checked="" type="checkbox"/> Method 2 (based on IP port number) - recommended <input type="checkbox"/> Method 3 (browsing for static data) - optional	IP address IP port number	
1.3.17 Time synchronization support:	<input type="checkbox"/> DNP3 LAN procedure (function code 24) <input checked="" type="checkbox"/> DNP3 Write Time (not recommended over LAN) <input type="checkbox"/> Other, explain <input type="checkbox"/> Not Supported		

1.4 LINK LAYER	Capabilities	Current Value	If configurable list methods
1.4.1 Data Link Address: <i>Indicates if the link address is configurable over the entire valid range of 0 to 65,519. Data link addresses 0xFFFF0 through 0xFFFFF are reserved for broadcast or other special purposes.</i>	<input type="checkbox"/> Fixed at <input checked="" type="checkbox"/> Configurable, range 0 to 65519 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	1	software ControlEdge Builder Vers 140 or later ----- --
1.4.2 DNP3 Source Address Validation: <i>Indicates whether the Outstation will filter out requests not from a specific source address.</i>	<input checked="" type="checkbox"/> Never <input checked="" type="checkbox"/> Always, one address allowed (shown in 1.4.3) <input type="checkbox"/> Always, any one of multiple addresses allowed (each selectable as shown in 1.4.3) <input type="checkbox"/> Sometimes, explain	Never	software ControlEdge Builder Vers 140 or later ----- --
1.4.3 DNP3 Source Address(es) expected when Validation is Enabled: <i>Selects the allowed source address(es)</i>	<input type="checkbox"/> Configurable to any 16 bit DNP Data Link Address value <input checked="" type="checkbox"/> Configurable, range 0 to 65519 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	30000	software ControlEdge Builder Vers 140 or later ----- --
1.4.4 Self Address Support using address 0xFFFC: <i>If an Outstation receives a message with a destination address of 0xFFFC it shall respond normally with its own source address. It must be possible to disable this feature if supported.</i>	<input checked="" type="checkbox"/> Yes (only allowed if configurable) <input checked="" type="checkbox"/> No	No	software ControlEdge Builder Vers 140 or later ----- --

1.4.5 Sends Confirmed User Data Frames: <i>A list of conditions under which the device transmits confirmed link layer services (TEST_LINK_STATES, RESET_LINK_STATES, CONFIRMED_USER_DATA).</i>	<input checked="" type="checkbox"/> Never <input checked="" type="checkbox"/> Always <input checked="" type="checkbox"/> Sometimes, explain Multi-fragment	Never	software ControlEdge Builder Vers 140 or later ----- --
1.4.6 Data Link Layer Confirmation Timeout: <i>This timeout applies to any secondary data link message that requires a confirm or response (link reset, link status, user data, etc).</i>	<input type="checkbox"/> None <input type="checkbox"/> Fixed at ms <input checked="" type="checkbox"/> Configurable, range 0 to 2147483647 ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain	2000ms	software ControlEdge Builder Vers 140 or later ----- --
1.4.7 Maximum Data Link Retries: <i>The number of times the device will retransmit a frame that requests Link Layer confirmation.</i>	<input type="checkbox"/> None <input type="checkbox"/> Fixed at <input checked="" type="checkbox"/> Configurable, range 0 to 255 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	3	software ControlEdge Builder Vers 140 or later ----- --
1.4.8 Maximum number of octets Transmitted in a Data Link Frame: <i>This number includes the CRCs. With a length field of 255, the maximum size would be 292.</i>	<input type="checkbox"/> Fixed at <input checked="" type="checkbox"/> Configurable, range 28 to 292 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	292	
1.4.9 Maximum number of octets that can be Received in a Data Link Frame: <i>This number includes the CRCs. With a field length of 255, the maximum size would be 292. The device must be able to receive 292 octets to be compliant.</i>	<input type="checkbox"/> Fixed at <input checked="" type="checkbox"/> Configurable, range 28 to 292 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	292	

1.5 APPLICATION LAYER	Capabilities	Current Value	If configurable list methods
1.5.1 Maximum number of octets Transmitted in an Application Layer Fragment other than File Transfer: <i>This size does not include any transport or frame octets. - Masters must provide a setting less than or equal to 249 to be compliant. - Outstations must provide a setting less than or equal to 2048 to be compliant. Note: The current value of this outstation parameter is available remotely using protocol object Group 0 Variation 240.</i>	<input type="checkbox"/> Fixed at <input checked="" type="checkbox"/> Configurable, range 256 to 65535 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	2048	
1.5.2 Maximum number of octets Transmitted in an Application Layer Fragment containing File Transfer:	<input type="checkbox"/> Fixed at <input checked="" type="checkbox"/> Configurable, range 256 to 65535 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	2048	
1.5.3 Maximum number of octets that can be received in an Application Layer Fragment: <i>This size does not include any transport or frame octets. - Masters must provide a setting greater than or equal to 2048 to be compliant. - Outstations must provide a setting greater than or equal to 249 to be compliant. Note: The current value of this outstation parameter is available remotely using protocol object Group 0 Variation 241.</i>	<input type="checkbox"/> Fixed at <input checked="" type="checkbox"/> Configurable, range 256 to 65535 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	2048	

1.5.4 Timeout waiting for Complete Application Layer Fragment: <i>Timeout if all frames of a message fragment are not received in the specified time. Measured from time first frame of a fragment is received until the last frame is received.</i>	<input checked="" type="checkbox"/> None <input type="checkbox"/> Fixed at ms <input type="checkbox"/> Configurable, range to ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain	None	
1.5.5 Maximum number of objects allowed in a single control request for CROB (Group 12): <i>Note: The current value of this outstation parameter is available remotely using protocol object Group 0 Variation 216.</i>	<input checked="" type="checkbox"/> Fixed at 10 (enter 0 if controls are not supported for CROB) <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain	10	
1.5.6 Maximum number of objects allowed in a single control request for Analog Outputs (Group 41):	<input checked="" type="checkbox"/> Fixed at 10 (enter 0 if controls are not supported for Analog Outputs) <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain	10	
1.5.7 Maximum number of objects allowed in a single control request for Data Sets (Groups 85, 86, 87):	<input checked="" type="checkbox"/> Fixed at 0 (enter 0 if controls are not supported for Data Sets) <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain	0	
1.5.8 Supports mixed object groups (AOBs, CROBs and Data Sets) in the same control request:	<input type="checkbox"/> Not applicable - controls are not supported <input checked="" type="checkbox"/> Yes <input checked="" type="checkbox"/> No	Yes	
1.5.9. User Data: <i>A user data entry</i>			

1.7 FILL OUT THE FOLLOWING ITEMS FOR OUTSTATIONS ONLY	Capabilities	Current Value	If configurable list methods
1.7.1 Timeout waiting for Application Confirm of solicited response message:	<input type="checkbox"/> None <input type="checkbox"/> Fixed at ms <input checked="" type="checkbox"/> Configurable, range 0 to 2147483647 ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain	10000ms	software ControlEdge Builder Vers 140 or later ----- --
1.7.2 How often is time synchronization required from the master: <i>Details of when the master needs to perform a time synchronization to ensure that the outstation clock does not drift outside of an acceptable tolerance. If the option to relate this to IIN1.4 is used then details of when IIN1.4 is asserted are in section 1.10.2.</i>	<input checked="" type="checkbox"/> Never needs time <input type="checkbox"/> Within seconds after IIN1.4 is set <input type="checkbox"/> Periodically, fixed at seconds <input checked="" type="checkbox"/> Periodically, between 0 and 2147483647 seconds	Periodically, every 1800 seconds.	software ControlEdge Builder Vers 140 or later ----- --
1.7.3 Device Trouble Bit IIN1.6: <i>If IIN1.6 device trouble bit is set under certain conditions, explain the possible causes.</i>	<input checked="" type="checkbox"/> Never used <input type="checkbox"/> Reason for setting	Never used	
1.7.4 File Handle Timeout: <i>If there is no activity referencing a file handle for a configurable length of time, the outstation must do an automatic close on the file. The timeout value must be configurable up to 1 hour. When this condition occurs the outstation will send a File Transport Status Object (obj grp 70 var 6) using a status code value of handle expired (0x02).</i>	<input checked="" type="checkbox"/> Not applicable, files not supported <input type="checkbox"/> Fixed at ms <input type="checkbox"/> Configurable, range to ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain	Not applicable	

1.7.5 Event Buffer Overflow Behavior:	<input checked="" type="checkbox"/> Discard the oldest event <input checked="" type="checkbox"/> Discard the newest event <input type="checkbox"/> Other, explain	Discard oldest	software ControlEdge Builder Vers 140 or later ----- --
1.7.6 Event Buffer Organization: <i>Explain how event buffers are arranged (per Object Group, per Class, single buffer etc) and provide their sizes.</i>	per Object Group	per Object Group	
1.7.7 Sends Multi-Fragment Responses: <i>Indicates whether an Outstation sends multi-fragment responses (Masters do not send multi-fragment requests).</i>	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	Yes	
1.7.8 Last Fragment Confirmation: <i>Indicates whether the Outstation requests confirmation of the last fragment of a multi-fragment response.</i>	<input type="checkbox"/> Always <input checked="" type="checkbox"/> Sometimes, explain Only when it contains events <input type="checkbox"/> Never	Sometimes	
1.7.9 DNP Command Settings preserved through a device restart: <i>If any of these settings are written through the DNP protocol and they are not preserved through a restart of the Outstation, the Master will have to write them again after it receives a response in which the Restart IIN bit is set.</i>	<input type="checkbox"/> Assign Class <input type="checkbox"/> Analog Deadbands <input type="checkbox"/> Data Set Prototypes <input type="checkbox"/> Data Set Descriptors <input type="checkbox"/> Function Code 31 Activate Configuration		

1.8 OUTSTATION UNSOLICITED RESPONSE SUPPORT	Capabilities	Current Value	If configurable list methods
1.8.1 Supports Unsolicited Reporting: <i>When the unsolicited response mode is configured "off", the device is to behave exactly like an equivalent device that has no support for unsolicited responses. If set to "on", the Outstation will send a null Unsolicited Response after it restarts, then wait for an Enable Unsolicited Response command from the master before sending additional Unsolicited Responses containing event data.</i>	<input type="checkbox"/> Not Supported <input checked="" type="checkbox"/> Configurable, selectable from On and Off	On	software ControlEdge Builder Vers 140 or later ----- --
1.8.2 Master Data Link Address: <i>The destination address of the master device where the unsolicited responses will be sent.</i>	<input type="checkbox"/> Fixed at <input checked="" type="checkbox"/> Configurable, range 0 to 65519 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	30000	software ControlEdge Builder Vers 140 or later ----- --
1.8.3 Unsolicited Response Confirmation Timeout: <i>This is the amount of time that the outstation will wait for an Application Layer confirmation back from the master indicating that the master received the unsolicited response message. As a minimum, the range of configurable values must include times from one second to one minute. This parameter may be the same one that is used for normal, solicited, application confirmation timeouts, or it may be a separate parameter.</i>	<input type="checkbox"/> Fixed at ms <input checked="" type="checkbox"/> Configurable, range 0 to 2147483647ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain	10000 ms	software ControlEdge Builder Vers 140 or later ----- --
1.8.4 Number of Unsolicited Retries: <i>This is the number of retries that an outstation transmits in each unsolicited response series if it does not receive confirmation back from the master. The configured value includes identical and regenerated retry messages. One of the choices must provide for an indefinite (and potentially infinite) number of transmissions.</i>	<input checked="" type="checkbox"/> None <input type="checkbox"/> Fixed at <input checked="" type="checkbox"/> Configurable, range 0 to 65535 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Always infinite, never gives up	3	software ControlEdge Builder Vers 140 or later ----- --

1.8.5. User Data: <i>A user data entry</i>			
---	--	--	--

1.9 OUTSTATION UNSOLICITED RESPONSE TRIGGER CONDITIONS	Capabilities	Current Value	If configurable list methods
1.9.1 Number of class 1 events:	<input checked="" type="checkbox"/> Class 1 not used to trigger Unsolicited Responses <input type="checkbox"/> Fixed at <input checked="" type="checkbox"/> Configurable, range 1 to 255 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	5	software ControlEdge Builder Vers 140 or later ----- --
1.9.2 Number of class 2 events:	<input checked="" type="checkbox"/> Class 2 not used to trigger Unsolicited Responses <input type="checkbox"/> Fixed at <input checked="" type="checkbox"/> Configurable, range 1 to 255 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	5	software ControlEdge Builder Vers 140 or later ----- --
1.9.3 Number of class 3 events:	<input checked="" type="checkbox"/> Class 3 not used to trigger Unsolicited Responses <input type="checkbox"/> Fixed at <input checked="" type="checkbox"/> Configurable, range 1 to 255 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	5	software ControlEdge Builder Vers 140 or later ----- --
1.9.4 Total number of events from any class:	<input checked="" type="checkbox"/> Total Number of Events not used to trigger Unsolicited Responses <input type="checkbox"/> Fixed at <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe		
1.9.5 Hold time after class 1 event: <i>A configurable value of 0 indicates that responses are not delayed due to this parameter.</i>	<input checked="" type="checkbox"/> Class 1 not used to trigger Unsolicited Responses <input type="checkbox"/> Fixed at ms <input checked="" type="checkbox"/> Configurable, range 0 to 2147483647 ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe	5000 ms	software ControlEdge Builder Vers 140 or later ----- --
1.9.6 Hold time after class 2 event: <i>A configurable value of 0 indicates that responses are not delayed due to this parameter.</i>	<input checked="" type="checkbox"/> Class 2 not used to trigger Unsolicited Responses <input type="checkbox"/> Fixed at ms <input checked="" type="checkbox"/> Configurable, range 0 to 2147483647 ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe	5000 ms	software ControlEdge Builder Vers 140 or later ----- --
1.9.7 Hold time after class 3 event: <i>A configurable value of 0 indicates that responses are not delayed due to this parameter.</i>	<input checked="" type="checkbox"/> Class 3 not used to trigger Unsolicited Responses <input type="checkbox"/> Fixed at ms <input checked="" type="checkbox"/> Configurable, range 0 to 2147483647 ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe	5000 ms	software ControlEdge Builder Vers 140 or later ----- --
1.9.8 Hold time after event assigned to any class: <i>A configurable value of 0 indicates that responses are not delayed due to this parameter.</i>	<input checked="" type="checkbox"/> Class events not used to trigger Unsolicited Responses <input type="checkbox"/> Fixed at ms <input type="checkbox"/> Configurable, range to ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe		

1.9.9 Retrigger Hold Time: <i>The hold-time timer may be retriggered for each new event detected (increased possibility of capturing all the changes in a single response) or not retriggered (giving the master a guaranteed update time).</i>	<input type="checkbox"/> Hold-time timer will be retriggered for each new event detected (may get more changes in next response) <input checked="" type="checkbox"/> Hold-time timer will not be retriggered for each new event detected (guaranteed update time)	Not retriggered	
1.9.10 Other Unsolicited Response Trigger Conditions:	<input checked="" type="checkbox"/> NONE	Other, NONE	

1.10 OUTSTATION PERFORMANCE	Capabilities	Current Value	If configurable list methods
1.10.1 Maximum Time Base Drift (milliseconds per minute): <i>If the device is synchronized by DNP, what is the clock drift rate over the full operating temperature range.</i>	<input checked="" type="checkbox"/> Fixed at 0ms <input type="checkbox"/> Range to ms <input type="checkbox"/> Selectable from ms <input type="checkbox"/> Other, describe	0 ms	
1.10.2 When does outstation set IIN1.4: <i>When does the outstation set the internal indication IIN1.4 NEED_TIME</i>	<input checked="" type="checkbox"/> Never <input checked="" type="checkbox"/> Asserted at startup until first Time Synchronization request received <input type="checkbox"/> Periodically every seconds <input type="checkbox"/> Periodically, range to seconds <input type="checkbox"/> Periodically, selectable from seconds <input type="checkbox"/> seconds after last time sync <input type="checkbox"/> Range to seconds after last time sync <input type="checkbox"/> Selectable from seconds after last time sync <input type="checkbox"/> When time error may have drifted by ms <input type="checkbox"/> When time error may have drifted by range to ms <input type="checkbox"/> When time error may have drifted by selectable from ms		software ControlEdge Builder Vers 140 or later ----- --
1.10.3 Maximum Internal Time Reference Error when set via DNP (ms): <i>The difference between the time set in DNP Write Time message, and the time actually set in the outstation.</i>	<input checked="" type="checkbox"/> Fixed at 0ms <input type="checkbox"/> Range to ms <input type="checkbox"/> Selectable from ms <input type="checkbox"/> Other, describe	0 ms	
1.10.4 Maximum Delay Measurement Error (ms): <i>The difference between the time reported in the delay measurement response and the actual time between receipt of the delay measurement request and issuing the delay measurement reply.</i>	<input checked="" type="checkbox"/> Fixed at 0ms <input type="checkbox"/> Range to ms <input type="checkbox"/> Selectable from ms <input type="checkbox"/> Other, describe	0 ms	
1.10.5 Maximum Response Time (ms): <i>The amount of time an outstation will take to respond upon receipt of a valid request. This does not include the message transmission time.</i>	<input checked="" type="checkbox"/> Fixed at 0ms <input type="checkbox"/> Range to ms <input type="checkbox"/> Selectable from ms <input type="checkbox"/> Other, describe	0 ms	
1.10.6 Maximum time from start-up to IIN 1.4 assertion (ms):	<input checked="" type="checkbox"/> Fixed at 0ms <input type="checkbox"/> Range to ms <input type="checkbox"/> Selectable from ms <input type="checkbox"/> Other, describe	0 ms	
1.10.7 Maximum Event Time-tag error for local Binary and Double Bit I/O (ms): <i>The error between the time-tag reported and the absolute time of the physical event. This error includes the Internal Time Reference Error. Note: The current value of this parameter is available remotely using protocol object Group 0 Variation 217.</i>	<input checked="" type="checkbox"/> Fixed at 0ms <input type="checkbox"/> Range to ms <input type="checkbox"/> Selectable from ms <input type="checkbox"/> Other, describe	0 ms	

1.10.8 Maximum Event Time-tag error for local I/O other than Binary and Double Bit data types (ms):	<input checked="" type="checkbox"/> Fixed at 0ms <input type="checkbox"/> Range to ms <input type="checkbox"/> Selectable from ms <input type="checkbox"/> Other, describe	0 ms	
---	---	------	--

1.11 INDIVIDUAL FIELD OUTSTATION PARAMETERS	Value of Current Setting	If configurable list methods
1.11.1 User-assigned location name or code string (same as g0v245):		
1.11.2 User-assigned ID code/number string (same as g0v246):		
1.11.3 User-assigned name string for the outstation (same as g0v247):		
1.11.4 Device Serial Number string (same as g0v248):		

1.12 SECURITY PARAMETERS	Capabilities	Current Value	If configurable list methods
1.12.1 DNP3 device support for secure authentication: <i>The support for secure authentication is optional in DNP3 devices. Indicate here if the device supports secure authentication.</i> <i>If the device does not support secure authentication then ignore the rest of this section.</i> <i>If the device does support secure authentication then specify the version(s) that are supported in the device. The version number is an integer value defined in the DNP3 Specification. The Secure Authentication procedure defined in IEEE 1815-2010 is version 2. The Secure Authentication procedure defined in IEEE 1815-2012 is version 5.</i>	<input type="checkbox"/> Secure Authentication not supported If Secure Authentication is supported, what Version(s) are supported: <input checked="" type="checkbox"/> Fixed at 5 <input type="checkbox"/> Configurable, selectable from	Supports security Version: 5	software ControlEdge Builder Vers R171.3 and primary release post R172 ----- --
1.12.2 Maximum number of users: <i>The secure authentication algorithm provides support for multiple users. The device must support details for each user (update keys, session keys, etc). A user is identified by a 16-bit user number, allowing a maximum of 65535 users. Devices are not mandated to support this number of potential users. Indicate here the actual limit to the number of simultaneous users that can be supported.</i>	Maximum number of users supported: 25	Maximum number of users supported: 25	software ControlEdge Builder Vers R171.3 and primary release post R172 ----- --
1.12.3 Security message response timeout: <i>Authentication of critical messages may involve additional message exchanges (challenges and responses) which can require an extension to the normal DNP3 message response timeout. This timeout specifies an additional time to be used when the extra security transactions are involved. The maximum allowable timeout extension should not exceed 120 seconds.</i>	<input type="checkbox"/> Fixed at ms <input checked="" type="checkbox"/> Configurable, range 0 to 4294967295ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe	2000 ms	software ControlEdge Builder Vers R171.3 and primary release post R172 ----- --
1.12.4 Aggressive mode of operation (receive): <i>DNP3 devices may (optionally) accept "aggressive" mode requests, where challenge data used for authentication is appended to a critical message rather than needing to be solicited via a separate message exchange.</i>		<input checked="" type="radio"/> Yes, accepts aggressive mode requests <input type="radio"/> No, does not accept aggressive mode requests	software ControlEdge Builder Vers R171.3 and primary release post R172 ----- --

<p>1.12.5 Aggressive mode of operation (issuing):</p> <p><i>DNP3 devices must support the issuing of "aggressive" mode of operation, where challenge data used for authentication is appended to a critical message rather than needing to be solicited via a separate message exchange. Specific instances of devices may have the use of aggressive mode switched off.</i></p>		<p><input checked="" type="radio"/> Yes, issues aggressive mode requests</p> <p><input type="radio"/> No, does not issue aggressive mode requests</p>	<p>software ControlEdge Builder Vers R171.3 and primary release post R172</p> <p>----- --</p>
<p>1.12.6 Session key change interval:</p> <p><i>To counter an attack that compromises the session key, the session key is changed at regular intervals. The maximum interval is 2 hours. Outstation devices invalidate the current set of session keys if they have not been changed by the master station after a period of twice this configured value.</i></p> <p><i>To accommodate systems with infrequent communications, this change interval can be disabled and just the session key change message count used (see 1.12.7)</i></p>	<p><input type="checkbox"/> Can be disabled</p> <p>When enabled</p> <p><input checked="" type="checkbox"/> Configurable, range 0 to 4294967295seconds</p>	<p>Enabled 900 seconds</p>	<p>software ControlEdge Builder Vers R171.3 and primary release post R172</p> <p>----- --</p>
<p>1.12.7 Session key change message count:</p> <p><i>In addition to changing the session key at regular intervals, the key shall also be changed after a specified number of messages have been exchanged. The maximum allowable value for this message count is 10,000</i></p>	<p><input checked="" type="checkbox"/> Configurable, range 0 to 4294967295</p>	<p>2000</p>	<p>software ControlEdge Builder Vers R171.3 and primary release post R172</p> <p>----- --</p>
<p>1.12.8 Maximum error count:</p> <p><i>To assist in countering denial of service attacks, a DNP3 device shall stop replying with error codes after a number of successive authentication failures. This error count has a maximum value of 10. Setting the error count to zero inhibits all error messages.</i></p>	<p><input checked="" type="checkbox"/> Configurable, range 0 to 4294967295</p>	<p>2</p>	<p>software ControlEdge Builder Vers R171.3 and primary release post R172</p> <p>----- --</p>
<p>1.12.9 MAC algorithm requested in a challenge exchange:</p> <p><i>Part of the authentication message is hashed using an MAC algorithm. Secure Authentication version 2 specifies that DNP3 devices must support SHA-1 and may optionally support SHA-256 for this hashing process. Secure Authentication version 5 specifies that SHA-256 is the default. The output of the MAC algorithm is truncated (the resulting length dependant on the media being used).</i></p>	<p><input checked="" type="checkbox"/> SHA-1 (truncated to the leftmost 4 octets)</p> <p><input checked="" type="checkbox"/> SHA-1 (truncated to the leftmost 8 octets)</p> <p><input checked="" type="checkbox"/> SHA-1 (truncated to the leftmost 10 octets)</p> <p><input checked="" type="checkbox"/> SHA-256 (truncated to the leftmost 8 octets)</p> <p><input checked="" type="checkbox"/> SHA-256 (truncated to the leftmost 16 octets)</p> <p><input checked="" type="checkbox"/> AES-GMAC</p> <p><input type="checkbox"/> Other, explain:</p>		<p>software ControlEdge Builder Vers R171.3 and primary release post R172</p> <p>----- --</p>
<p>1.12.10 Key-wrap algorithm to encrypt session keys:</p> <p><i>During the update of a session key, the key is encrypted using AES-128 or optionally using other algorithms.</i></p>	<p><input checked="" type="checkbox"/> AES-128</p> <p><input checked="" type="checkbox"/> AES-256</p> <p><input checked="" type="checkbox"/> RSAES-OAEP-1024 / SHA-1</p> <p><input checked="" type="checkbox"/> RSAES-OAEP-2048 / SHA-256</p> <p><input checked="" type="checkbox"/> RSAES-OAEP-3072 / SHA-256</p> <p><input type="checkbox"/> Other, explain:</p>		<p>software ControlEdge Builder Vers R171.3 and primary release post R172</p> <p>----- --</p>

<p>1.12.11 Cipher Suites used with DNP implementations using TLS:</p> <p><i>When TLS is supported, DNP3 Secure Authentication mandates the support of TLS_RSA_WITH_AES_128_SHA. The specification has a number of recommended cipher suite combinations. Indicate the supported Cipher Suites for implementations using TLS.</i></p>	<input checked="" type="checkbox"/> Not relevant - TLS is not used <input type="checkbox"/> TLS_RSA encrypted with AES128 <input type="checkbox"/> TLS_RSA encrypted with RC4_128 <input type="checkbox"/> TLS_RSA encrypted with 3DES_EDE_CBC <input type="checkbox"/> TLS_DH, signed with DSS, encrypted with 3DES_EDE_CBC <input type="checkbox"/> TLS_DH, signed with RSA, encrypted with 3DES_EDE_CBC <input type="checkbox"/> TLS_DHE, signed with DSS, encrypted with 3DES_EDE_CBC <input type="checkbox"/> TLS_DHE, signed with RSA, encrypted with 3DES_EDE_CBC <input type="checkbox"/> TLS_DH, signed with DSS, encrypted with AES128 <input type="checkbox"/> TLS_DH, signed with DSS, encrypted with AES256 <input type="checkbox"/> TLS_DH encrypted with AES128 <input type="checkbox"/> TLS_DH encrypted with AES256 <input type="checkbox"/> Other, explain:		software ControlEdge Builder Vers R171.3 and primary release post R172 ----- --
<p>1.12.12 Change cipher request timeout:</p> <p><i>Implementations using TLS shall terminate the connection if a response to a change cipher request is not seen within this timeout period.</i></p>	<input checked="" type="checkbox"/> Not relevant - TLS is not used <input type="checkbox"/> Fixed at <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe		software ControlEdge Builder Vers R171.3 and primary release post R172 ----- --
<p>1.12.13 Number of Certificate Authorities supported:</p> <p><i>Implementations using TLS shall support at least 4 Certificate Authorities. Indicate the number supported.</i></p>			software ControlEdge Builder Vers R171.3 and primary release post R172 ----- --
<p>1.12.14 Certificate Revocation check time:</p> <p><i>Implementations using TLS shall evaluate Certificate Revocation Lists on a periodic basis, terminating a connection if a certificate is revoked.</i></p>	<input checked="" type="checkbox"/> Not relevant - TLS is not used <input type="checkbox"/> Fixed at hours <input type="checkbox"/> Configurable, range to hours <input type="checkbox"/> Configurable, selectable from hours <input type="checkbox"/> Configurable, other, describe		software ControlEdge Builder Vers R171.3 and primary release post R172 ----- --

<p>1.12.15 Additional critical function codes:</p> <p><i>The DNP3 specification defines those messages with specific function codes that are critical and must be used as part of a secure authentication message exchange. Messages with other function codes are optional and changes to this list should be noted here.</i></p> <p><i>Note: Secure Authentication version 5 defines additional functions as critical that were not considered critical in version 2. These are shown in the next column annotated with "V2 only".</i></p>	<p>Additional function codes that are to be considered as "critical":</p> <input checked="" type="checkbox"/> 0 (Confirm) <input checked="" type="checkbox"/> 1 (Read) <input checked="" type="checkbox"/> 7 (Immediate freeze) <input checked="" type="checkbox"/> 8 (Immediate freeze - no ack) <input checked="" type="checkbox"/> 9 (Freeze-and-clear) <input checked="" type="checkbox"/> 10 (Freeze-and-clear - no ack) <input checked="" type="checkbox"/> 11 (Freeze-at-time) <input checked="" type="checkbox"/> 12 (Freeze-at-time - no ack) <input checked="" type="checkbox"/> 22 (Assign Class) <input checked="" type="checkbox"/> 23 (Delay Measurement) <input checked="" type="checkbox"/> 25 (Open File) - V2 only <input checked="" type="checkbox"/> 26 (Close File) - V2 only <input checked="" type="checkbox"/> 27 (Delete File) - V2 only <input checked="" type="checkbox"/> 28 (Get File Info) - V2 only <input checked="" type="checkbox"/> 30 (Abort File) - V2 only		<p>software ControlEdge Builder Vers R171.3 and primary release post R172 ----- --</p>
<p>1.12.16 Other critical fragments:</p> <p><i>Other critical transactions can be defined and should be detailed here. Examples could be based on time (for example: the first transaction after a communications session is established). Other examples could be based on specific data objects (for example: the reading of specific data points).</i></p>			<p>software ControlEdge Builder Vers R171.3 and primary release post R172 ----- --</p>
<p>1.12.17 Support for remote update key changes:</p> <p><i>Devices implementing secure authentication version 5 of later have the option to support remote update key changes. If remote update key change is supported then the procedure using symmetric cryptography is mandatory. Additional support for the procedure using asymmetric (public key) cryptography is optional.</i></p>	<input checked="" type="checkbox"/> Remote update key change by symmetric cryptography <input type="checkbox"/> Remote update key change by asymmetric cryptography	<p>Using symmetric cryptography</p>	<p>software ControlEdge Builder Vers R171.3 and primary release post R172 ----- --</p>

1.13 BROADCAST FUNCTIONALITY	Capabilities	Current Value	If configurable list methods
<p>This section indicates which functions are supported by the device when using broadcast addresses. Note that it is mandatory for outstations to be configurable to enable or disable the support for each function in order to comply with the requirements of the IED conformance tests dated 2012 and later.</p> <p>Note that this section shows only entries that may have a meaningful purpose when used with broadcast requests.</p>			
<p>1.13.1 Support for broadcast functionality:</p>	<input type="radio"/> Disabled <input type="radio"/> Enabled <input checked="" type="radio"/> Configurable	<p>Enabled</p>	

<p>1.13.2 Write functions (FC = 2) supported with broadcast requests:</p>	<p>Write clock (g50v1 with qualifier code 07)</p> <p><input type="radio"/> Disabled</p> <p><input type="radio"/> Enabled</p> <p><input checked="" type="radio"/> Configurable, other (described elsewhere)</p> <p>Write last recorded time (g50v3 with qualifier code 07)</p> <p><input type="radio"/> Disabled</p> <p><input type="radio"/> Enabled</p> <p><input checked="" type="radio"/> Configurable, other (described elsewhere)</p> <p>Clear restart (g80v1 with qualifier code 00 and index = 7, value = 0)</p> <p><input type="radio"/> Disabled</p> <p><input type="radio"/> Enabled</p> <p><input checked="" type="radio"/> Configurable, other (described elsewhere)</p> <p>Write to any other group / variation / qualifier code</p> <p><input type="radio"/> Disabled</p> <p><input type="radio"/> Enabled</p> <p><input checked="" type="radio"/> Configurable, other (described elsewhere)</p>	<p>Write clock: Enabled</p> <p>Write last recorded time: Enabled</p> <p>Clear restart: Enabled</p> <p>Write any other: Enabled</p>	<p>Clock: Time:</p> <p>Restart: Other:</p>
<p>1.13.3 Direct operate functions (FC = 5) supported with broadcast requests:</p>	<p><input type="radio"/> Disabled</p> <p><input type="radio"/> Enabled</p> <p><input checked="" type="radio"/> Configurable, other (described elsewhere)</p>	<p>Enabled</p>	
<p>1.13.4 Direct operate, no acknowledgement functions (FC = 6) supported with broadcast requests:</p>	<p><input type="radio"/> Disabled</p> <p><input type="radio"/> Enabled</p> <p><input checked="" type="radio"/> Configurable, other (described elsewhere)</p>	<p>Enabled</p>	
<p>1.13.5 Immediate freeze functions (FC = 7) supported with broadcast requests:</p>	<p><input type="radio"/> Disabled</p> <p><input type="radio"/> Enabled</p> <p><input checked="" type="radio"/> Configurable, other (described elsewhere)</p>	<p>Enabled</p>	
<p>1.13.6 Immediate freeze, no acknowledgement functions (FC = 8) supported with broadcast requests:</p>	<p><input type="radio"/> Disabled</p> <p><input type="radio"/> Enabled</p> <p><input checked="" type="radio"/> Configurable, other (described elsewhere)</p>	<p>Enabled</p>	
<p>1.13.7 Freeze and clear functions (FC = 9) supported with broadcast requests:</p>	<p><input type="radio"/> Disabled</p> <p><input type="radio"/> Enabled</p> <p><input checked="" type="radio"/> Configurable, other (described elsewhere)</p>	<p>Enabled</p>	
<p>1.13.8 Freeze and clear, no acknowledgement functions (FC = 10) supported with broadcast requests:</p>	<p><input type="radio"/> Disabled</p> <p><input type="radio"/> Enabled</p> <p><input checked="" type="radio"/> Configurable, other (described elsewhere)</p>	<p>Enabled</p>	
<p>1.13.9 Freeze at time functions (FC = 11) supported with broadcast requests:</p>	<p><input type="radio"/> Disabled</p> <p><input type="radio"/> Enabled</p> <p><input checked="" type="radio"/> Configurable, other (described elsewhere)</p>	<p>Enabled</p>	
<p>1.13.10 Freeze at time, no acknowledgement functions (FC = 12) supported with broadcast requests:</p>	<p><input type="radio"/> Disabled</p> <p><input type="radio"/> Enabled</p> <p><input checked="" type="radio"/> Configurable, other (described elsewhere)</p>	<p>Enabled</p>	
<p>1.13.11 Cold restart functions (FC = 13) supported with broadcast requests:</p>	<p><input type="radio"/> Disabled</p> <p><input type="radio"/> Enabled</p> <p><input checked="" type="radio"/> Configurable, other (described elsewhere)</p>	<p>Enabled</p>	
<p>1.13.12 Warm restart functions (FC = 14) supported with broadcast requests:</p>	<p><input type="radio"/> Disabled</p> <p><input type="radio"/> Enabled</p> <p><input checked="" type="radio"/> Configurable, other (described elsewhere)</p>	<p>Enabled</p>	
<p>1.13.13 Initialize data functions (FC = 15) supported with broadcast requests:</p>	<p><input type="radio"/> Disabled</p> <p><input type="radio"/> Enabled</p> <p><input checked="" type="radio"/> Configurable, other (described elsewhere)</p>	<p>Enabled</p>	
<p>1.13.14 Initialize application functions (FC = 16) supported with broadcast requests:</p>	<p><input type="radio"/> Disabled</p> <p><input type="radio"/> Enabled</p> <p><input checked="" type="radio"/> Configurable, other (described elsewhere)</p>	<p>Enabled</p>	

1.13.15 Start application functions (FC = 17) supported with broadcast requests:	<input type="radio"/> Disabled <input type="radio"/> Enabled <input checked="" type="radio"/> Configurable, other (described elsewhere)	Enabled	
1.13.16 Stop application functions (FC = 18) supported with broadcast requests:	<input type="radio"/> Disabled <input type="radio"/> Enabled <input checked="" type="radio"/> Configurable, other (described elsewhere)	Enabled	
1.13.17 Save configuration functions (FC = 19) supported with broadcast requests:	<input type="radio"/> Disabled <input type="radio"/> Enabled <input checked="" type="radio"/> Configurable, other (described elsewhere)	Enabled	
1.13.18 Enable unsolicited functions (FC = 20) supported with broadcast requests:	Enable unsolicited by event Class (g60v2, g60v3 and g60v4 with qualifier code 06) <input type="radio"/> Disabled <input type="radio"/> Enabled <input checked="" type="radio"/> Configurable, other (described elsewhere) Enable unsolicited for any other group / variation / qualifier code <input type="radio"/> Disabled <input type="radio"/> Enabled <input checked="" type="radio"/> Configurable, other (described elsewhere)	By event class: Enabled By any other: Enabled	Class: Other:
1.13.19 Disable unsolicited functions (FC = 21) supported with broadcast requests:	Disable unsolicited by event Class (g60v2, g60v3 and g60v4 with qualifier code 06) <input type="radio"/> Disabled <input type="radio"/> Enabled <input checked="" type="radio"/> Configurable, other (described elsewhere) Disable unsolicited for any other group / variation / qualifier code <input type="radio"/> Disabled <input type="radio"/> Enabled <input checked="" type="radio"/> Configurable, other (described elsewhere)	By event class: Enabled By any other: Enabled	Class: Other:
1.13.20 Assign class functions (FC = 22) supported with broadcast requests:	<input type="radio"/> Disabled <input type="radio"/> Enabled <input checked="" type="radio"/> Configurable, other (described elsewhere)	Enabled	
1.13.21 Record current time functions (FC = 24) supported with broadcast requests:	<input type="radio"/> Disabled <input type="radio"/> Enabled <input checked="" type="radio"/> Configurable, other (described elsewhere)	Enabled	
1.13.22 Activate configuration functions (FC = 31) supported with broadcast requests:	<input type="radio"/> Disabled <input type="radio"/> Enabled <input checked="" type="radio"/> Configurable, other (described elsewhere)	Enabled	

2 Mapping between DNP3 and IEC 61850 Objects

This optional section allows each configuration parameter or point in the DNP Data map to be tied to an attribute in the IEC 61850 object models (and vice-versa).

Earlier versions of this section (up to version 2.07) used mappings based on an "access point" (section 2.1.1 and then a series of XPath references (section 2.1.2). Section 2.1.2 has been superseded in version 2.08 onwards with mappings defined using either predefined rules (section 2.1.3) or specified as an equation (section 2.1.4). The list of pre-defined rules is found in the IEEE 1815-1 document.

The following display has been selected to be in a tabular form.

MAPPING BETWEEN DNP3 AND IEC 61850 OBJECTS

3 Capabilities and Current Settings for Device Database (Outstation only)

The following tables identify the capabilities and current settings for each DNP3 data type. Details defining the data points available in the device are shown in part 5 of this Device Profile.

3.1 SINGLE-BIT BINARY INPUT POINTS			
Static (Steady-State) Object Number: 1			
Event Object Number: 2			
	Capabilities (leave tick-boxes blank if this data type is not supported)	Current Value	If configurable list methods
3.1.1 Static Variation reported when variation 0 requested or in response to Class polls:	<input checked="" type="checkbox"/> Variation 1 - Single-bit packed format <input checked="" type="checkbox"/> Variation 2 - Single-bit with flag <input type="checkbox"/> Based on point index (add column to table in part 5)	Two Note: Configurable on a per-object basis.	software ControlEdge Builder Vers 140 or later ----- --
3.1.2 Event Variation reported when variation 0 requested or in response to Class polls: <i>Note: The support for binary input events can be determined remotely using protocol object Group 0 Variation 237.</i>	<input checked="" type="checkbox"/> Variation 1 - without time <input checked="" type="checkbox"/> Variation 2 - with absolute time <input checked="" type="checkbox"/> Variation 3 - with relative time <input type="checkbox"/> Based on point index (add column to table in part 5)	Two Note: Configurable on a per-object basis.	software ControlEdge Builder Vers 140 or later ----- --
3.1.3 Event reporting mode: <i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event. "All events" must be checked to be compliant.</i>	<input type="checkbox"/> Only most recent <input checked="" type="checkbox"/> All events <input type="checkbox"/> Based on point index (add column to table in part 5)	All events	
3.1.4 Binary Inputs included in Class 0 response:	<input type="checkbox"/> Always <input type="checkbox"/> Never <input checked="" type="checkbox"/> Only if point is assigned to a class <input type="checkbox"/> Based on point index (add column to table in part 5)	If assigned	

3.2 DOUBLE-BIT INPUT POINTS			
Static (Steady-State) Object Number: 3			
Event Object Number: 4			
	Capabilities (leave tick-boxes blank if this data type is not supported)	Current Value	If configurable list methods
3.2.1 Static Variation reported when variation 0 requested or in response to Class polls: <i>Note: The support for double-bit inputs can be determined remotely using protocol object Group 0 Variation 234.</i>	<input checked="" type="checkbox"/> Variation 1 - Double-bit packed format <input checked="" type="checkbox"/> Variation 2 - Double-bit with flag <input type="checkbox"/> Based on point index (add column to table in part 5)	Two Note: Configurable on a per-object basis.	software ControlEdge Builder Vers 140 or later ----- --
3.2.2 Event Variation reported when variation 0 requested or in response to Class polls:	<input checked="" type="checkbox"/> Variation 1 - without time <input checked="" type="checkbox"/> Variation 2 - with absolute time <input checked="" type="checkbox"/> Variation 3 - with relative time <input type="checkbox"/> Based on point index (add column to table in part 5)	Two Note: Configurable on a per-object basis.	software ControlEdge Builder Vers 140 or later ----- --
3.2.3 Event reporting mode: <i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event. "All events" must be checked to be compliant.</i>	<input type="checkbox"/> Only most recent <input checked="" type="checkbox"/> All events <input type="checkbox"/> Based on point index (add column to table in part 5)	All events	
3.2.4 Double Bit Inputs included in Class 0 response:	<input type="checkbox"/> Always <input type="checkbox"/> Never <input checked="" type="checkbox"/> Only if point is assigned to a class <input type="checkbox"/> Based on point index (add column to table in part 5)	If assigned	

3.3 BINARY OUTPUT STATUS AND CONTROL RELAY OUTPUT BLOCK			
Binary Output Status Object Number: 10			
Binary Output Event Object Number: 11			
CROB Object Number: 12			
Binary Output Command Event Object Number: 13			
	Capabilities (leave tick-boxes blank if this data type is not supported)	Current Value	If configurable list methods
3.3.1 Minimum pulse time allowed with Trip, Close and Pulse On commands:	<input checked="" type="checkbox"/> Fixed at 0 ms (hardware may limit this further) <input type="checkbox"/> Based on point index (add column to table in part 5)	Fixed at 0 ms	
3.3.2 Maximum pulse time allowed with Trip, Close and Pulse On commands:	<input checked="" type="checkbox"/> Fixed at 2147483647 ms (hardware may limit this further) <input type="checkbox"/> Based on point index (add column to table in part 5)	Fixed at 2147483647 ms	
3.3.3 Binary Output Status included in Class 0 response:	<input type="checkbox"/> Always <input type="checkbox"/> Never <input checked="" type="checkbox"/> Only if point is assigned to a class <input type="checkbox"/> Based on point index (add column to table in part 5)	If assigned	
3.3.4 Reports Output Command Event Objects:	<input type="checkbox"/> Never <input type="checkbox"/> Only upon a successful Control <input checked="" type="checkbox"/> Upon all control attempts	On all attempts	
3.3.5 Static Variation reported when variation 0 requested or in response to Class polls:	<input checked="" type="checkbox"/> Variation 1 - Continuous control <input checked="" type="checkbox"/> Variation 2 - Continuous control, binary output status <input type="checkbox"/> Based on point index (add column to table in part 5)	Two Note: Configurable on a per-object basis.	software ControlEdge Builder Vers 140 or later ----- --
3.3.6 Event Variation reported when variation 0 requested or in response to Class polls: <i>Note: The support for binary output events can be determined remotely using protocol object Group 0 Variation 222.</i>	<input checked="" type="checkbox"/> Variation 1 - without time <input checked="" type="checkbox"/> Variation 2 - with absolute time <input type="checkbox"/> Based on point index (add column to table in part 5)	Two Note: Configurable on a per-object basis.	software ControlEdge Builder Vers 140 or later ----- --
3.3.7 Command Event Variation reported when variation 0 requested or in response to Class polls:	<input checked="" type="checkbox"/> Variation 1 - without time <input checked="" type="checkbox"/> Variation 2 - with absolute time <input type="checkbox"/> Based on point index (add column to table in part 5)	Two Note: Configurable on a per-object basis.	software ControlEdge Builder Vers 140 or later ----- --
3.3.8 Event reporting mode: <i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event.</i>	<input type="checkbox"/> Only most recent <input checked="" type="checkbox"/> All events	All events	
3.3.9 Command Event reporting mode: <i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event.</i>	<input type="checkbox"/> Only most recent <input checked="" type="checkbox"/> All events	All events	
3.3.10 Maximum Time between Select and Operate:	<input type="checkbox"/> Not Applicable <input type="checkbox"/> Fixed at seconds <input checked="" type="checkbox"/> Configurable, range 1 to 2147483seconds <input type="checkbox"/> Configurable, selectable from seconds <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain <input type="checkbox"/> Based on point index (add column to table in part 5)	5 seconds	software ControlEdge Builder Vers 140 or later ----- --

3.4 COUNTERS / FROZEN COUNTERS
Static Counter Object Number: 20
Static Frozen Counter Object Number: 21
Counter Event Object Number: 22
Frozen Counter Event Object Number: 23

	Capabilities (leave tick-boxes blank if this data type is not supported)	Current Value	If configurable list methods
3.4.1 Static Counter Variation reported when variation 0 requested or in response to Class polls:	<input checked="" type="checkbox"/> Variation 1 - 32-bit with flag <input checked="" type="checkbox"/> Variation 2 - 16-bit with flag <input checked="" type="checkbox"/> Variation 5 - 32-bit without flag <input checked="" type="checkbox"/> Variation 6 - 16-bit without flag <input type="checkbox"/> Based on point index (add column to table in part 5)	One Note: Configurable on a per-object basis.	software ControlEdge Builder Vers 140 or later ----- --
3.4.2 Counter Event Variation reported when variation 0 requested or in response to Class polls: <i>Note: The support for counter events can be determined remotely using protocol object Group 0 Variation 227.</i>	<input checked="" type="checkbox"/> Variation 1 - 32-bit with flag <input checked="" type="checkbox"/> Variation 2 - 16-bit with flag <input checked="" type="checkbox"/> Variation 5 - 32-bit with flag and time <input checked="" type="checkbox"/> Variation 6 - 16-bit with flag and time <input type="checkbox"/> Based on point index (add column to table in part 5)	Five Note: Configurable on a per-object basis.	software ControlEdge Builder Vers 140 or later ----- --
3.4.3 Counters included in Class 0 response:	<input type="checkbox"/> Always <input type="checkbox"/> Never <input checked="" type="checkbox"/> Only if point is assigned to a class <input type="checkbox"/> Based on point index (add column to table in part 5)	If assigned	
3.4.4 Counter Event reporting mode: <i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event. Only the most recent event is typically reported for Counters. When reporting only the most recent event the counter value returned in the response may be either the value at the time that the event is queued or it may be the value at the time of the response.</i>	<input type="checkbox"/> A: Only most recent (value at time of event) <input type="checkbox"/> B: Only most recent (value at time of response) <input checked="" type="checkbox"/> C: All events <input type="checkbox"/> Based on point index (add column to table in part 5)	All events	
3.4.5 Static Frozen Counter Variation reported when variation 0 requested or in response to Class polls:	<input checked="" type="checkbox"/> Variation 1 - 32-bit with flag <input checked="" type="checkbox"/> Variation 2 - 16-bit with flag <input checked="" type="checkbox"/> Variation 5 - 32-bit with flag and time <input checked="" type="checkbox"/> Variation 6 - 16-bit with flag and time <input checked="" type="checkbox"/> Variation 9 - 32-bit without flag <input checked="" type="checkbox"/> Variation 10 - 16-bit without flag <input type="checkbox"/> Based on point index (add column to table in part 5)	Five Note: Configurable on a per-object basis.	software ControlEdge Builder Vers 140 or later ----- --
3.4.6 Frozen Counter Event Variation reported when variation 0 requested or in response to Class polls: <i>Note: The support for frozen counter events can be determined remotely using protocol object Group 0 Variation 225.</i>	<input checked="" type="checkbox"/> Variation 1 - 32-bit with flag <input checked="" type="checkbox"/> Variation 2 - 16-bit with flag <input checked="" type="checkbox"/> Variation 5 - 32-bit without flag <input checked="" type="checkbox"/> Variation 6 - 16-bit without flag <input type="checkbox"/> Based on point index (add column to table in part 5)	Five Note: Configurable on a per-object basis.	software ControlEdge Builder Vers 140 or later ----- --
3.4.7 Frozen Counters included in Class 0 response:	<input type="checkbox"/> Always <input type="checkbox"/> Never <input checked="" type="checkbox"/> Only if point is assigned to a class <input type="checkbox"/> Based on point index (add column to table in part 5)	If assigned	
3.4.8 Frozen Counter Event reporting mode: <i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event. All events are typically reported for Frozen Counters</i>	<input type="checkbox"/> Only most recent frozen value <input checked="" type="checkbox"/> All frozen values <input type="checkbox"/> Based on point index (add column to table in part 5)	All events	

3.4.9 Counters Roll Over at:	<input checked="" type="checkbox"/> 16 Bits (65,535) <input checked="" type="checkbox"/> 32 Bits (4,294,967,295) <input type="checkbox"/> Fixed at <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Based on point index (add column to table in part 5)	4,294,967,295	
3.4.10 Counters frozen by means of:	<input checked="" type="checkbox"/> Master Request <input type="checkbox"/> Freezes itself without concern for time of day <input type="checkbox"/> Freezes itself and requires time of day <input type="checkbox"/> Other, explain:	Master Request	

3.5 ANALOG INPUT POINTS
Static (Steady-State) Object Number: 30
Event Object Number: 32
Deadband Object Number: 34

	Capabilities (leave tick-boxes blank if this data type is not supported)	Current Value	If configurable list methods
3.5.1 Static Variation reported when variation 0 requested or in response to Class polls:	<input checked="" type="checkbox"/> Variation 1 - 32-bit with flag <input checked="" type="checkbox"/> Variation 2 - 16-bit with flag <input checked="" type="checkbox"/> Variation 3 - 32-bit without flag <input checked="" type="checkbox"/> Variation 4 - 16-bit without flag <input checked="" type="checkbox"/> Variation 5 - single-precision floating point with flag <input checked="" type="checkbox"/> Variation 6 - double-precision floating point with flag <input type="checkbox"/> Based on point index (add column to table in part 5)	Five Note: Configurable on a per-object basis.	software ControlEdge Builder Vers 140 or later ----- --
3.5.2 Event Variation reported when variation 0 requested or in response to Class polls: <i>Note: The support for analog input events can be determined remotely using protocol object Group 0 Variation 231.</i>	<input checked="" type="checkbox"/> Variation 1 - 32-bit without time <input checked="" type="checkbox"/> Variation 2 - 16-bit without time <input checked="" type="checkbox"/> Variation 3 - 32-bit with time <input checked="" type="checkbox"/> Variation 4 - 16-bit with time <input checked="" type="checkbox"/> Variation 5 - single-precision floating point w/o time <input checked="" type="checkbox"/> Variation 6 - double-precision floating point w/o time <input checked="" type="checkbox"/> Variation 7 - single-precision floating point with time <input checked="" type="checkbox"/> Variation 8 - double-precision floating point with time <input type="checkbox"/> Based on point index (add column to table in part 5)	Seven Note: Configurable on a per-object basis.	software ControlEdge Builder Vers 140 or later ----- --
3.5.3 Event reporting mode: <i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event. Only the most recent event is typically reported for Analog Inputs. When reporting only the most recent event the analog value returned in the response may be either the value at the time that the event is queued or it may be the value at the time of the response.</i>	<input type="checkbox"/> A: Only most recent (value at time of event) <input type="checkbox"/> B: Only most recent (value at time of response) <input checked="" type="checkbox"/> C: All events <input type="checkbox"/> Based on point index (add column to table in part 5)	All events	
3.5.4 Analog Inputs included in Class 0 response:	<input type="checkbox"/> Always <input type="checkbox"/> Never <input checked="" type="checkbox"/> Only if point is assigned to a class <input type="checkbox"/> Based on point index (add column to table in part 5)	If assigned	

3.5.5 How Deadbands are set:	<input type="checkbox"/> A. Global Fixed <input checked="" type="checkbox"/> B. Configurable through DNP <input type="checkbox"/> C. Configurable via other means <input type="checkbox"/> D. Other, explain: <input checked="" type="checkbox"/> Based on point index - column in part 5 specifies which of the options applies, B, C, or D	Based on point index	software ControlEdge Builder Vers 140 or later ----- --
3.5.6 Analog Deadband Algorithm: simple- just compares the difference from the previous reported value integrating- keeps track of the accumulated change other- indicating another algorithm	<input checked="" type="checkbox"/> Simple <input checked="" type="checkbox"/> Integrating <input type="checkbox"/> Other, explain: <input type="checkbox"/> Based on point index (add column to table in part 5)	Simple	
3.5.7 Static Frozen Analog Input Variation reported when variation 0 requested or in response to Class polls:	<input type="checkbox"/> Variation 1 - 32-bit with flag <input type="checkbox"/> Variation 2 - 16-bit with flag <input type="checkbox"/> Variation 3 - 32-bit with time-of-freeze <input type="checkbox"/> Variation 4 - 16-bit with time-of-freeze <input type="checkbox"/> Variation 5 - 32-bit without flag <input type="checkbox"/> Variation 6 - 16-bit without flag <input type="checkbox"/> Variation 7 - single-precision floating point with flag <input type="checkbox"/> Variation 8 - double-precision floating point with flag <input type="checkbox"/> Based on point index (add column to table in part 5)		
3.5.8 Frozen Analog Input Event Variation reported when variation 0 requested or in response to Class polls: <i>Note: The support for frozen analog input events can be determined remotely using protocol object Group 0 Variation 230.</i>	<input type="checkbox"/> Variation 1 - 32-bit without time <input type="checkbox"/> Variation 2 - 16-bit without time <input type="checkbox"/> Variation 3 - 32-bit with time <input type="checkbox"/> Variation 4 - 16-bit with time <input type="checkbox"/> Variation 5 - single-precision floating point w/o time <input type="checkbox"/> Variation 6 - double-precision floating point w/o time <input type="checkbox"/> Variation 7 - single-precision floating point with time <input type="checkbox"/> Variation 8 - double-precision floating point with time <input type="checkbox"/> Based on point index (add column to table in part 5)		
3.5.9 Frozen Analog Inputs included in Class 0 response:	<input type="checkbox"/> Always <input type="checkbox"/> Never <input type="checkbox"/> Only if point is assigned to a class <input type="checkbox"/> Based on point index (add column to table in part 5)		
3.5.10 Frozen Analog Input Event reporting mode: <i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event. All events are typically reported for Frozen Analog Inputs.</i>	<input type="checkbox"/> Only most recent frozen value <input type="checkbox"/> All frozen values <input type="checkbox"/> Based on point index (add column to table in part 5)		

3.6 ANALOG OUTPUT STATUS AND ANALOG OUTPUT CONTROL BLOCK Analog Output Status Object Number: 40 Analog Output Control Block Object Number: 41 Analog Output Event Object Number: 42 Analog Output Command Event Object Number: 43			
	Capabilities (leave tick-boxes blank if this data type is not supported)	Current Value	If configurable list methods

<p>3.6.1 Static Analog Output Status Variation reported when variation 0 requested or in response to Class polls:</p>	<input checked="" type="checkbox"/> Variation 1 - 32-bit with flag <input checked="" type="checkbox"/> Variation 2 - 16-bit with flag <input checked="" type="checkbox"/> Variation 3 - single-precision floating point with flag <input checked="" type="checkbox"/> Variation 4 - double-precision floating point with flag <input type="checkbox"/> Based on point index (add column to table in part 5)	<p>Three</p> <p>Note: Configurable on a per-object basis.</p>	<p>software ControlEdge Builder Vers 140 or later</p> <p>-----</p> <p>--</p>
<p>3.6.2 Analog Output Status included in Class 0 response:</p>	<input type="checkbox"/> Always <input type="checkbox"/> Never <input checked="" type="checkbox"/> Only if point is assigned to a class <input type="checkbox"/> Based on point index (add column to table in part 5)	<p>If assigned</p>	
<p>3.6.3 Reports Output Command Event Objects:</p>	<input type="checkbox"/> Never <input type="checkbox"/> Only upon a successful Control <input checked="" type="checkbox"/> Upon all control attempts	<p>On all attempts</p>	
<p>3.6.4 Event Variation reported when variation 0 requested or in response to Class polls:</p> <p><i>Note: The support for analog output events can be determined remotely using protocol object Group 0 Variation 219.</i></p>	<input checked="" type="checkbox"/> Variation 1 - 32-bit without time <input checked="" type="checkbox"/> Variation 2 - 16-bit without time <input checked="" type="checkbox"/> Variation 3 - 32-bit with time <input checked="" type="checkbox"/> Variation 4 - 16-bit with time <input checked="" type="checkbox"/> Variation 5 - single-precision floating point w/o time <input checked="" type="checkbox"/> Variation 6 - double-precision floating point w/o time <input checked="" type="checkbox"/> Variation 7 - single-precision floating point with time <input checked="" type="checkbox"/> Variation 8 - double-precision floating point with time <input type="checkbox"/> Based on point index (add column to table in part 5)	<p>Seven</p> <p>Note: Configurable on a per-object basis.</p>	<p>software ControlEdge Builder Vers 140 or later</p> <p>-----</p> <p>--</p>
<p>3.6.5 Command Event Variation reported when variation 0 requested or in response to Class polls:</p>	<input checked="" type="checkbox"/> Variation 1 - 32-bit without time <input checked="" type="checkbox"/> Variation 2 - 16-bit without time <input checked="" type="checkbox"/> Variation 3 - 32-bit with time <input checked="" type="checkbox"/> Variation 4 - 16-bit with time <input checked="" type="checkbox"/> Variation 5 - single-precision floating point w/o time <input checked="" type="checkbox"/> Variation 6 - double-precision floating point w/o time <input checked="" type="checkbox"/> Variation 7 - single-precision floating point with time <input checked="" type="checkbox"/> Variation 8 - double-precision floating point with time <input type="checkbox"/> Based on point index (add column to table in part 5)	<p>Seven</p> <p>Note: Configurable on a per-object basis.</p>	<p>software ControlEdge Builder Vers 140 or later</p> <p>-----</p> <p>--</p>
<p>3.6.6 Event reporting mode:</p> <p><i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event.</i></p>	<input type="checkbox"/> Only most recent <input checked="" type="checkbox"/> All events	<p>All events</p>	
<p>3.6.7 Command Event reporting mode:</p> <p><i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event.</i></p>	<input type="checkbox"/> Only most recent <input checked="" type="checkbox"/> All events	<p>All events</p>	
<p>3.6.8 Maximum Time between Select and Operate:</p>	<input type="checkbox"/> Not Applicable <input type="checkbox"/> Fixed at seconds <input checked="" type="checkbox"/> Configurable, range 1 to 2147483seconds <input type="checkbox"/> Configurable, selectable from seconds <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain <input type="checkbox"/> Based on point index (add column to table in part 5)	<p>5 seconds</p>	<p>software ControlEdge Builder Vers 140 or later</p> <p>-----</p> <p>--</p>

3.7 SEQUENTIAL FILE TRANSFER Object Number: 70			
	Capabilities	Current Value	If configurable list methods
3.7.1 File Transfer Supported:	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No (set 3.7.6 to "Fixed at 0" and do not complete other entries in section 3.7)	No	
3.7.2 File Authentication: <i>Indicates whether a valid authentication key must be obtained prior to open and delete requests.</i>	<input type="checkbox"/> Always <input type="checkbox"/> Sometimes, explain <input type="checkbox"/> Never	Never	
3.7.3 File Append Mode: <i>Indicates if a file can be opened and appended to versus just overwritten.</i>	<input type="checkbox"/> Always <input type="checkbox"/> Sometimes, explain <input type="checkbox"/> Never	Never	
3.7.4 Permissions Support: <i>Indicates the device is capable of using the indicated permissions.</i>	<input type="checkbox"/> Owner Read Allowed: 0x0100 <input type="checkbox"/> Owner Write Allowed: 0x0080 <input type="checkbox"/> Owner Execute Allowed: 0x0040 <input type="checkbox"/> Group Read Allowed: 0x0020 <input type="checkbox"/> Group Write Allowed: 0x0010 <input type="checkbox"/> Group Execute Allowed: 0x0008 <input type="checkbox"/> World Read Allowed: 0x0004 <input type="checkbox"/> World Write Allowed: 0x0002 <input type="checkbox"/> World Execute Allowed: 0x0001		
3.7.5 Multiple Blocks in a Fragment: <i>File data is transferred in a series of blocks of a maximum specified size. This indicates whether only a single block or multiple blocks will be sent in fragment.</i>	<input type="checkbox"/> Yes <input type="checkbox"/> No	No	
3.7.6 Max number of Files Open at one time:	<input checked="" type="checkbox"/> Fixed at 0 <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	0	

3.8 OCTET STRING POINTS Static (Steady-State) Object Number: 110 Event Object Number: 111			
	Capabilities	Current Value	If configurable list methods
3.8.1 Event reporting mode: <i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event.</i>	<input type="checkbox"/> Only most recent <input checked="" type="checkbox"/> All events <input type="checkbox"/> Based on point index (add column to table in part 5)	All events	
3.8.2 Octet Strings included in Class 0 response:	<input type="checkbox"/> Always <input type="checkbox"/> Never <input checked="" type="checkbox"/> Only if point is assigned to a class <input type="checkbox"/> Based on point index (add column to table in part 5)	If assigned	

3.10 DATA SET PROTOTYPE Object Number: 85 Variation Number: 1			
	Capabilities	Current Value	If configurable list methods

This version of the Device Profile has no requirement for describing Data Set Prototype capabilities and current settings. This page is intentionally left blank, existing as placeholder for future use.

3.11 DATA SET DESCRIPTOR CONTENTS AND CHARACTERISTICS

Object Number: 86

Variation Numbers: 1 and 2

This version of the Device Profile has no requirement for describing Data Set Descriptor capabilities and current settings. This page is intentionally left blank, existing as placeholder for future use.

4 Implementation Table

The following implementation table identifies which object groups and variations, function codes and qualifiers the device supports in both requests and responses. The *Request* columns identify all requests that may be sent by a Master, or all requests that must be parsed by an Outstation. The *Response* columns identify all responses that must be parsed by a Master, or all responses that may be sent by an Outstation.

DNP OBJECT GROUP & VARIATION			REQUEST Master may issue Outstation must parse		RESPONSE Master must parse Outstation may issue	
Object Group Number	Variation Number	Description	Function Codes (dec)	Qualifier Codes (hex)	Function Codes (dec)	Qualifier Codes (hex)
0	211	Device Attributes - Identification of support for user-specific attributes	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	212	Device Attributes - Number of master-defined data set prototypes	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	213	Device Attributes - Number of outstation-defined data set prototypes	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	214	Device Attributes - Number of master-defined data sets	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	215	Device Attributes - Number of outstation-defined data sets	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)

0	216	Device Attributes - Maximum number of binary output objects per request	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	217	Device Attributes - Local timing accuracy	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	218	Device Attributes - Duration of time accuracy	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	219	Device Attributes - Support for analog output events	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	220	Device Attributes - Maximum analog output index	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	221	Device Attributes - Number of analog outputs	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	222	Device Attributes - Support for binary output events	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	223	Device Attributes - Maximum binary output index	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)

0	224	Device Attributes - Number of binary outputs	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	225	Device Attributes - Support for frozen counter events	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	226	Device Attributes - Support for frozen counters	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	227	Device Attributes - Support for counter events	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	228	Device Attributes - Maximum counter index	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	229	Device Attributes - Number of counter points	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	230	Device Attributes - Support for frozen analog inputs	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	231	Device Attributes - Support for analog input events	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)

0	232	Device Attributes - Maximum analog input index	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	233	Device Attributes - Number of analog input points	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	234	Device Attributes - Support for double-bit binary input events	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	235	Device Attributes - Maximum double-bit binary index	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	236	Device Attributes - Number of double-bit binary input points	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	237	Device Attributes - Support for binary input events	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	238	Device Attributes - Maximum binary input index	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)
0	239	Device Attributes - Number of binary input points	1(<i>read</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00 (<i>start-stop</i>), 01 (<i>start-stop</i>), 17 (<i>index</i>), 28 (<i>index</i>)

0	240	Device Attributes - Maximum transmit fragment size	1(read)	00 (start-stop), 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00 (start-stop), 01 (start-stop), 17 (index), 28 (index)
0	240	Device Attributes - Maximum transmit fragment size	2(write)	00 (start-stop), 01 (start-stop)		
0	241	Device Attributes - Maximum receive fragment size	1(read)	00 (start-stop), 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00 (start-stop), 01 (start-stop), 17 (index), 28 (index)
0	242	Device Attributes - Device manufacturer's software version	1(read)	00 (start-stop), 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00 (start-stop), 01 (start-stop), 17 (index), 28 (index)
0	243	Device Attributes - Device manufacturer's hardware version	1(read)	00 (start-stop), 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00 (start-stop), 01 (start-stop), 17 (index), 28 (index)
0	245	Device Attributes - User-assigned location name	1(read)	00 (start-stop), 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00 (start-stop), 01 (start-stop), 17 (index), 28 (index)
0	245	Device Attributes - User-assigned location name	2(write)	00 (start-stop), 01 (start-stop)		
0	246	Device Attributes - User assigned ID code/number	1(read)	00 (start-stop), 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00 (start-stop), 01 (start-stop), 17 (index), 28 (index)
0	246	Device Attributes - User assigned ID code/number	2(write)	00 (start-stop), 01 (start-stop)		
0	247	Device Attributes - User-assigned device name	1(read)	00 (start-stop), 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00 (start-stop), 01 (start-stop), 17 (index), 28 (index)
0	247	Device Attributes - User-assigned device name	2(write)	00 (start-stop), 01 (start-stop)		

0	248	Device Attributes - Device serial number	1(read)	00 (start-stop), 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00 (start-stop), 01 (start-stop), 17 (index), 28 (index)
0	250	Device Attributes - Device manufacturer's product name and model	1(read)	00 (start-stop), 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00 (start-stop), 01 (start-stop), 17 (index), 28 (index)
0	252	Device Attributes - Device manufacturer's name	1(read)	00 (start-stop), 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00 (start-stop), 01 (start-stop), 17 (index), 28 (index)
0	254	Device Attributes - Non-specific all attributes request	1(read)	00 (start-stop), 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)		
0	255	Device Attributes - List of attribute variations	1(read)	00 (start-stop), 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00 (start-stop), 01 (start-stop), 5B (free format)
1	0	Binary Input - any variation	1(read)	00, 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)		
1	0	Binary Input - any variation	22(assign class)	00, 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)		
1	1	Binary Input - Single-bit packed	1(read)	00, 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00, 01 (start-stop), 17, 28 (index)

1	2	Binary Input - Single-bit with flag	1(read)	00, 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00, 01 (start-stop), 17, 28 (index)
2	0	Binary Input Change Event - any variation	1(read)	06 (no range, or all), 07, 08 (limited qty)		
2	1	Binary Input Change Event - without time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
2	1	Binary Input Change Event - without time			130 (Unsol. Resp.)	17, 28 (index)
2	2	Binary Input Change Event - with absolute time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
2	2	Binary Input Change Event - with absolute time			130 (Unsol. Resp.)	17, 28 (index)
2	3	Binary Input Change Event - with relative time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
2	3	Binary Input Change Event - with relative time			130 (Unsol. Resp.)	17, 28 (index)
3	0	Double-bit Input - any variation	1(read)	00, 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)		
3	0	Double-bit Input - any variation	22(assign class)	00, 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)		
3	1	Double-bit Input - Double-bit packed	1(read)	00, 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00, 01 (start-stop), 17, 28 (index)
3	2	Double-bit Input - with flag	1(read)	00, 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00, 01 (start-stop), 17, 28 (index)
4	0	Double-bit Input Change Event - any variation	1(read)	06 (no range, or all), 07, 08 (limited qty)		
4	1	Double-bit Input Change Event - without time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
4	1	Double-bit Input Change Event - without time			130 (Unsol. Resp.)	17, 28 (index)

4	2	Double-bit Input Change Event - with absolute time	1(<i>read</i>)	06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)	129 (<i>Response</i>)	17, 28 (<i>index</i>)
4	2	Double-bit Input Change Event - with absolute time			130 (<i>Unsol. Resp.</i>)	17, 28 (<i>index</i>)
4	3	Double-bit Input Change Event - with relative time	1(<i>read</i>)	06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)	129 (<i>Response</i>)	17, 28 (<i>index</i>)
4	3	Double-bit Input Change Event - with relative time			130 (<i>Unsol. Resp.</i>)	17, 28 (<i>index</i>)
10	0	Binary Output - any variation	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 28 (<i>index</i>)		
10	0	Binary Output - any variation	22(<i>assign class</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)		
10	1	Binary Output - packed format	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)
10	1	Binary Output - packed format	2(<i>write</i>)	00, 01 (<i>start-stop</i>)		
10	2	Continuous Control - output status with flags	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)
11	0	Binary Output Change Event - any variation	1(<i>read</i>)	06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)		
11	1	Binary Output Change Event - status without time	1(<i>read</i>)	06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)	129 (<i>Response</i>)	17, 28 (<i>index</i>)
11	1	Binary Output Change Event - status without time			130 (<i>Unsol. Resp.</i>)	17, 28 (<i>index</i>)
11	2	Binary Output Change Event - status with time	1(<i>read</i>)	06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)	129 (<i>Response</i>)	17, 28 (<i>index</i>)
11	2	Binary Output Change Event - status with time			130 (<i>Unsol. Resp.</i>)	17, 28 (<i>index</i>)
12	0	Binary Output Command (CROB) - any variation	22(<i>assign class</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)		
12	1	Binary Output Command (CROB) - control relay output block	3(<i>select</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
12	1	Binary Output Command (CROB) - control relay output block	4(<i>operate</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
12	1	Binary Output Command (CROB) - control relay output block	5(<i>direct op.</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request

12	1	Binary Output Command (CROB) - control relay output block	6(<i>direct op. no ack</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
12	2	Binary Output Command - pattern control block	3(<i>select</i>)	07 (<i>limited qty = 1</i>)	129 (<i>Response</i>)	echo of request
12	2	Binary Output Command - pattern control block	4(<i>operate</i>)	07 (<i>limited qty = 1</i>)	129 (<i>Response</i>)	echo of request
12	2	Binary Output Command - pattern control block	5(<i>direct op.</i>)	07 (<i>limited qty = 1</i>)	129 (<i>Response</i>)	echo of request
12	2	Binary Output Command - pattern control block	6(<i>direct op. no ack</i>)	07 (<i>limited qty = 1</i>)	129 (<i>Response</i>)	echo of request
12	3	Binary Output Command - pattern mask	3(<i>select</i>)	00, 01 (<i>start-stop</i>)	129 (<i>Response</i>)	echo of request
12	3	Binary Output Command - pattern mask	4(<i>operate</i>)	00, 01 (<i>start-stop</i>)	129 (<i>Response</i>)	echo of request
12	3	Binary Output Command - pattern mask	5(<i>direct op.</i>)	00, 01 (<i>start-stop</i>)	129 (<i>Response</i>)	echo of request
12	3	Binary Output Command - pattern mask	6(<i>direct op. no ack</i>)	00, 01 (<i>start-stop</i>)	129 (<i>Response</i>)	echo of request
13	0	Binary Output Command Event - any variation	1(<i>read</i>)	06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)		
13	1	Binary Output Command Event - without time	1(<i>read</i>)	06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)	129 (<i>Response</i>)	17, 28 (<i>index</i>)
13	1	Binary Output Command Event - without time			130 (<i>Unsol. Resp.</i>)	17, 28 (<i>index</i>)
13	2	Binary Output Command Event - with time	1(<i>read</i>)	06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)	129 (<i>Response</i>)	17, 28 (<i>index</i>)
13	2	Binary Output Command Event - with time			130 (<i>Unsol. Resp.</i>)	17, 28 (<i>index</i>)
20	0	Counter - any variation	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)		
20	0	Counter - any variation	22(<i>assign class</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)		
20	0	Counter - any variation	7(<i>freeze</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)		
20	0	Counter - any variation	8(<i>freeze, no ack</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)		
20	0	Counter - any variation	9(<i>freeze & clear</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)		

20	0	Counter - any variation	10(<i>frz & clr, no ack</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)		
20	1	Counter - 32-bit with flag	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)
20	2	Counter - 16-bit with flag	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)
20	5	Counter - 32-bit with flag and time	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)
20	6	Counter - 16-bit with flag and time	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)
21	0	Frozen Counter - any variation	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)		
21	0	Frozen Counter - any variation	22(<i>assign class</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)		
21	1	Frozen Counter - 32-bit with flag	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)
21	2	Frozen Counter - 16-bit with flag	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)

21	5	Frozen Counter - 32-bit with flag and time	1(read)	00, 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00, 01 (start-stop), 17, 28 (index)
21	6	Frozen Counter - 16-bit with flag and time	1(read)	00, 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00, 01 (start-stop), 17, 28 (index)
21	9	Frozen Counter - 32-bit with flag and time	1(read)	00, 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00, 01 (start-stop), 17, 28 (index)
21	10	Frozen Counter - 16-bit with flag and time	1(read)	00, 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00, 01 (start-stop), 17, 28 (index)
22	0	Counter Change Event - any variation	1(read)	06 (no range, or all), 07, 08 (limited qty)		
22	1	Counter Change Event - 32-bit with flag	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
22	1	Counter Change Event - 32-bit with flag			130 (Unsol. Resp.)	17, 28 (index)
22	2	Counter Change Event - 16-bit with flag	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
22	2	Counter Change Event - 16-bit with flag			130 (Unsol. Resp.)	17, 28 (index)
22	5	Counter Change Event - 32-bit with flag and time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
22	5	Counter Change Event - 32-bit with flag and time			130 (Unsol. Resp.)	17, 28 (index)
22	6	Counter Change Event - 16-bit with flag and time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
22	6	Counter Change Event - 16-bit with flag and time			130 (Unsol. Resp.)	17, 28 (index)
23	0	Frozen Counter Change Event - any variation	1(read)	06 (no range, or all), 07, 08 (limited qty)		
23	1	Frozen Counter Change Event - 32-bit with flag	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
23	1	Frozen Counter Change Event - 32-bit with flag			130 (Unsol. Resp.)	17, 28 (index)
23	2	Frozen Counter Change Event - 16-bit with flag	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
23	2	Frozen Counter Change Event - 16-bit with flag			130 (Unsol. Resp.)	17, 28 (index)

23	5	Frozen Counter Change Event - 32-bit with flag and time	1(<i>read</i>)	06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)	129 (<i>Response</i>)	17, 28 (<i>index</i>)
23	5	Frozen Counter Change Event - 32-bit with flag and time			130 (<i>Unsol. Resp.</i>)	17, 28 (<i>index</i>)
23	6	Frozen Counter Change Event - 16-bit with flag and time	1(<i>read</i>)	06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)	129 (<i>Response</i>)	17, 28 (<i>index</i>)
23	6	Frozen Counter Change Event - 16-bit with flag and time			130 (<i>Unsol. Resp.</i>)	17, 28 (<i>index</i>)
30	0	Analog Input - any variation	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>)		
30	0	Analog Input - any variation	22(<i>assign class</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)		
30	1	Analog Input - 32-bit with flag	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)
30	2	Analog Input - 16-bit with flag	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)
30	3	Analog Input - 32-bit without flag	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)
30	4	Analog Input - 16-bit without flag	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)
30	5	Analog Input - single-precision, floating-point with flag	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)
30	6	Analog Input - double-precision, floating-point with flag	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)

32	0	Analog Input Change Event - any variation	1(read)	06 (no range, or all), 07, 08 (limited qty)		
32	1	Analog Input Change Event - 32-bit without time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
32	1	Analog Input Event – 32-bit without time			130 (Unsol. Resp.)	17, 28 (index)
32	2	Analog Input Change Event - 16-bit without time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
32	2	Analog Input Change Event - 16-bit without time			130 (Unsol. Resp.)	17, 28 (index)
32	3	Analog Input Change Event - 32-bit with time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
32	3	Analog Input Change Event - 32-bit with time			130 (Unsol. Resp.)	17, 28 (index)
32	4	Analog Input Change Event - 16-bit with time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
32	4	Analog Input Change Event - 16-bit with time			130 (Unsol. Resp.)	17, 28 (index)
32	5	Analog Input Change Event - single-precision, floating-point without time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
32	5	Analog Input Change Event - single-precision, floating-point without time			130 (Unsol. Resp.)	17, 28 (index)
32	6	Analog Input Change Event - double-precision, floating-point without time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
32	6	Analog Input Change Event - double-precision, floating-point without time			130 (Unsol. Resp.)	17, 28 (index)
32	7	Analog Input Change Event - single-precision, floating-point with time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
32	7	Analog Input Change Event - single-precision, floating-point with time			130 (Unsol. Resp.)	17, 28 (index)
32	8	Analog Input Change Event - double-precision, floating-point with time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
32	8	Analog Input Change Event - double-precision, floating-point with time			130 (Unsol. Resp.)	17, 28 (index)
34	0	Analog Input Deadband - any variation	1(read)	00, 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)		
34	1	Analog Input Deadband - 16-bit	1(read)	00, 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty), 17, 27, 28 (index)	129 (Response)	00, 01 (start-stop), 17, 28 (index)
34	1	Analog Input Deadband - 16-bit	2(write)	00, 01 (start-stop), 07, 08 (limited qty), 17, 27, 28 (index)		

34	2	Analog Input Deadband - 32-bit	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)
34	2	Analog Input Deadband - 32-bit	2(<i>write</i>)	00, 01 (<i>start-stop</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)		
34	3	Analog Input Deadband - single-precision, floating-point	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)
34	3	Analog Input Deadband - single-precision, floating-point	2(<i>write</i>)	00, 01 (<i>start-stop</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)		
40	0	Analog Output Status - any variation	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)		
40	0	Analog Output Status - any variation	22(<i>assign class</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)		
40	1	Analog Output Status - 32-bit with flag	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)
40	2	Analog Output Status - 16-bit with flag	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)
40	3	Analog Output Status - single-precision, floating-point with flag	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)

40	4	Analog Output Status - double-precision, floating-point with flag	1(<i>read</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	00, 01 (<i>start-stop</i>), 17, 28 (<i>index</i>)
41	0	Analog Output Block - any variation	22(<i>assign class</i>)	00, 01 (<i>start-stop</i>), 06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>), 17, 27, 28 (<i>index</i>)		
41	1	Analog Output Block - 32-bit	3(<i>select</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
41	1	Analog Output Block - 32-bit	4(<i>operate</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
41	1	Analog Output Block - 32-bit	5(<i>direct op.</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
41	1	Analog Output Block - 32-bit	6(<i>direct op, no ack</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
41	2	Analog Output Block - 16-bit	3(<i>select</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
41	2	Analog Output Block - 16-bit	4(<i>operate</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
41	2	Analog Output Block - 16-bit	5(<i>direct op.</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
41	2	Analog Output Block - 16-bit	6(<i>direct op, no ack</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
41	3	Analog Output Block - single-precision, floating-point	3(<i>select</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
41	3	Analog Output Block - single-precision, floating-point	4(<i>operate</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
41	3	Analog Output Block - single-precision, floating-point	5(<i>direct op.</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
41	3	Analog Output Block - single-precision, floating-point	6(<i>direct op, no ack</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
41	4	Analog Output Block - double-precision, floating-point	3(<i>select</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
41	4	Analog Output Block - double-precision, floating-point	4(<i>operate</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
41	4	Analog Output Block - double-precision, floating-point	5(<i>direct op.</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
41	4	Analog Output Block - double-precision, floating-point	6(<i>direct op, no ack</i>)	17, 27, 28 (<i>index</i>)	129 (<i>Response</i>)	echo of request
42	0	Analog Output Change Event - any variation	1(<i>read</i>)	06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)		
42	1	Analog Output Change Event - 32-bit without time	1(<i>read</i>)	06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)	129 (<i>Response</i>)	17, 28 (<i>index</i>)
42	1	Analog Output Change Event - 32-bit without time			130 (<i>Unsol. Resp.</i>)	17, 28 (<i>index</i>)
42	2	Analog Output Change Event - 16-bit without time	1(<i>read</i>)	06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)	129 (<i>Response</i>)	17, 28 (<i>index</i>)
42	2	Analog Output Change Event - 16-bit without time			130 (<i>Unsol. Resp.</i>)	17, 28 (<i>index</i>)
42	3	Analog Output Change Event - 32-bit with time	1(<i>read</i>)	06 (<i>no range, or all</i>), 07, 08 (<i>limited qty</i>)	129 (<i>Response</i>)	17, 28 (<i>index</i>)
42	3	Analog Output Change Event - 32-bit with time			130 (<i>Unsol. Resp.</i>)	17, 28 (<i>index</i>)

42	4	Analog Output Change Event - 16-bit with time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
42	4	Analog Output Change Event - 16-bit with time			130 (Unsol. Resp.)	17, 28 (index)
42	5	Analog Output Change Event - single-precision, floating-point without time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
42	5	Analog Output Change Event - single-precision, floating-point without time			130 (Unsol. Resp.)	17, 28 (index)
42	6	Analog Output Change Event - double-precision, floating-point without time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
42	6	Analog Output Change Event - double-precision, floating-point without time			130 (Unsol. Resp.)	17, 28 (index)
42	7	Analog Output Change Event - single-precision, floating-point with time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
42	7	Analog Output Change Event - single-precision, floating-point with time			130 (Unsol. Resp.)	17, 28 (index)
42	8	Analog Output Change Event - double-precision, floating-point with time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
42	8	Analog Output Change Event - double-precision, floating-point with time			130 (Unsol. Resp.)	17, 28 (index)
43	0	Analog Output Command Event - any variation	1(read)	06 (no range, or all), 07, 08 (limited qty)		
43	1	Analog Output Command Event - 32-bit without time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
43	1	Analog Output Command Event - 32-bit without time			130 (Unsol. Resp.)	17, 28 (index)
43	2	Analog Output Command Event - 16-bit without time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
43	2	Analog Output Command Event - 16-bit without time			130 (Unsol. Resp.)	17, 28 (index)
43	3	Analog Output Command Event - 32-bit with time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
43	3	Analog Output Command Event - 32-bit with time			130 (Unsol. Resp.)	17, 28 (index)
43	4	Analog Output Command Event - 16-bit with time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
43	4	Analog Output Command Event - 16-bit with time			130 (Unsol. Resp.)	17, 28 (index)
43	5	Analog Output Command Event - single-precision, floating-point without time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
43	5	Analog Output Command Event - single-precision, floating-point without time			130 (Unsol. Resp.)	17, 28 (index)
43	6	Analog Output Command Event - double-precision, floating-point without time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
43	6	Analog Output Command Event - double-precision, floating-point without time			130 (Unsol. Resp.)	17, 28 (index)

43	7	Analog Output Command Event - single-precision, floating-point with time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
43	7	Analog Output Command Event - single-precision, floating-point with time			130 (Unsol. Resp.)	17, 28 (index)
43	8	Analog Output Command Event - double-precision, floating-point with time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
43	8	Analog Output Command Event - double-precision, floating-point with time			130 (Unsol. Resp.)	17, 28 (index)
50	1	Time and Date - absolute time	1(read)	07 (limited qty = 1)	129 (Response)	07 (limited qty = 1)
50	1	Time and Date - absolute time	2(write)	07 (limited qty = 1)		
50	3	Time and Date - absolute time at last recorded time	2(write)	07 (limited qty = 1)		
51	1	Time and Date CTO - absolute time, synchronized			129 (Response)	07 (limited qty = 1)
51	1	Time and Date CTO - absolute time, synchronized			130 (Unsol. Resp.)	07 (limited qty = 1)
51	2	Time and Date CTO - absolute time, unsynchronized			129 (Response)	07 (limited qty = 1)
51	2	Time and Date CTO - absolute time, unsynchronized			130 (Unsol. Resp.)	07 (limited qty = 1)
52	1	Time Delay - coarse			129 (Response)	07 (limited qty = 1)
52	2	Time Delay - fine			129 (Response)	07 (limited qty = 1)
60	1	Class Objects - class 0 data	1(read)	06 (no range, or all)		
60	1	Class Objects - class 0 data	22(assign class)	06 (no range, or all)		
60	2	Class Objects - class 1 data	1(read)	06 (no range, or all), 07, 08 (limited qty)		
60	2	Class Objects - class 1 data	20(enable unsol.)	06 (no range, or all)		
60	2	Class Objects - class 1 data	21(disable unsol.)	06 (no range, or all)		
60	2	Class Objects - class 1 data	22(assign class)	06 (no range, or all)		
60	3	Class Objects - class 2 data	1(read)	06 (no range, or all), 07, 08 (limited qty)		
60	3	Class Objects - class 2 data	20(enable unsol.)	06 (no range, or all)		
60	3	Class Objects - class 2 data	21(disable unsol.)	06 (no range, or all)		
60	3	Class Objects - class 2 data	22(assign class)	06 (no range, or all)		
60	4	Class Objects - class 3 data	1(read)	06 (no range, or all), 07, 08 (limited qty)		
60	4	Class Objects - class 3 data	20(enable unsol.)	06 (no range, or all)		
60	4	Class Objects - class 3 data	21(disable unsol.)	06 (no range, or all)		
60	4	Class Objects - class 3 data	22(assign class)	06 (no range, or all)		
80	1	Internal Indications - packed format	1(read)	00, 01 (start-stop)	129 (Response)	00, 01 (start-stop)
80	1	Internal Indications - packed format	2(write)	00 (start-stop)		

91	1	Status of Requested Operation			129 (Response)	07 (limited qty = 1)
----	---	-------------------------------	--	--	----------------	----------------------

5 Data Points List (outstation only)

This part of the Device Profile shows, for each data type, a table defining the data points available in the device or a description of how this information can be obtained if the database is configurable.

5.1 Definition of Binary Input Point List: <i>List of addressable points. Points that do not exist (for example, because an option is not installed) are omitted from the table.</i> <i>Note: the number of binary inputs present in the device, and the maximum binary input index, are available remotely using object Group 0 Variations 239 and 238.</i>	<input type="checkbox"/> Fixed, list shown in table below <input checked="" type="checkbox"/> Configurable (current list may be shown in table below) <input type="checkbox"/> Other, explain:
---	--

Binary Input points list:

Point Index	Name	Event Class Assigned (1, 2, 3 or none)	Name for State when value is 0	Name for State when value is 1	Description
-------------	------	--	--------------------------------	--------------------------------	-------------

5.2 Definition of Double Bit Input Point List: <i>List of addressable points. Points that do not exist (for example, because an option is not installed) are omitted from the table.</i> <i>Note: the number of double-bit inputs present in the device, and the maximum double-bit input index, are available remotely using object Group 0 Variations 236 and 235.</i>	<input type="checkbox"/> Fixed, list shown in table below <input checked="" type="checkbox"/> Configurable (current list may be shown in table below) <input type="checkbox"/> Other, explain:
---	--

Double-bit Input points list:

Point Index	Name	Event Class Assigned (1, 2, 3 or none)	Name for State when value is 0 (intermediate)	Name for State when value is 1 (off)	Name for State when value is 2 (on)	Name for State when value is 3 (indeterminate)	Description
-------------	------	--	---	--------------------------------------	-------------------------------------	--	-------------

5.3 Definition of Binary Output Status / Control Relay Output Block Points List: <i>List of addressable points. Points that do not exist (for example, because an option is not installed) are omitted from the table.</i> <i>Note: the number of binary outputs present in the device, and the maximum binary output index, are available remotely using object Group 0 Variations 224 and 223.</i>	<input type="checkbox"/> Fixed, list shown in table below <input checked="" type="checkbox"/> Configurable (current list may be shown in table below) <input type="checkbox"/> Other, explain:
---	--

Binary Output Status and CROB points list:

Point Index	Name	Select/Operate	Supported Control Operations										Event Class Assigned (1,2,3 or none)		Change	Command	Description
			Direct Operate	Direct Operate - No Ack	Pulse On	Pulse Off	Latch On	Latch Off	Trip	Close	Count > 1	Cancel Currently Running Operation	Name for State when value is 0	Name for State when value is 1			

5.4 Definition of Counter / Frozen Counter Point List: <i>List of addressable points. Points that do not exist (for example, because an option is not installed) are omitted from the table.</i> <i>Note: the number of counters present in the device, and the maximum counter index, are available remotely using object Group 0 Variations 229 and 228.</i>	<input type="checkbox"/> Fixed, list shown in table below <input checked="" type="checkbox"/> Configurable (current list may be shown in table below) <input type="checkbox"/> Other, explain:
---	--

Counter / Frozen Counter points list:

Point Index	Name	Event Class Assigned to Counter Events (1, 2, 3 or none)	Frozen Counter Exists (Yes or No)	Event Class Assigned to Frozen Counter Events (1, 2, 3 or none)	Description
-------------	------	--	-----------------------------------	---	-------------

5.5 Definition of Analog Input Point List:

List of addressable points. Points that do not exist (for example, because an option is not installed) are omitted from the table.

Note: the number of analog inputs present in the device, and the maximum analog input index, are available remotely using object Group 0 Variations 233 and 232.

Fixed, list shown in table below
 Configurable (current list may be shown in table below)
 Other, explain:

Analog Input points list:

Point Index	Name	Event Class Assigned (1, 2, 3 or none)	Transmitted Value		Scaling		Units	Resolution	Description
			Min int / ft	Max int / ft	Multiplier	Offset			

5.6 Definition of Analog Output Status / Analog Output Block Point List:

List of addressable points. Points that do not exist (for example, because an option is not installed) are omitted from the table.

Note: the number of analog outputs present in the device, and the maximum analog output index, are available remotely using object Group 0 Variations 221 and 220.

Fixed, list shown in table below
 Configurable (current list may be shown in table below)
 Other, explain:

Analog Output points list:

Point Index	Name	Supported Control Operations			Transmitted Value		Scaling		Units	Resolution	Event Class Assigned (1, 2, 3 or none)		Description
		Select/Operate	Direct Operate	Direct Operate - No Ack	Min	Max	Min	Max			Change	Command	

5.7 Definition of File Names that may be read or written:

Fixed, list shown in table below
 Configurable (current list may be shown in table below)
 Other, explain:

Sequential Files list:

File Name	Event Class Assigned (1, 2, 3 or none)	Authentication Required for:			Description
		Read	Write	Delete	

5.8 Definition of Octet String Point List:

List of addressable points. Points that do not exist (for example, because an option is not installed) are omitted from the table.

Fixed, list shown in table below
 Configurable (current list may be shown in table below)
 Other, explain:

Octet String points list:

Point Index	Name	Event Class Assigned (1, 2, 3 or none)	Description
-------------	------	--	-------------

5.9 Definition of Virtual Terminal Port Numbers:

List of addressable points. Points that do not exist (for example, because an option is not installed) are omitted from the table.

Fixed, list shown in table below
 Configurable (current list may be shown in table below)
 Other, explain:

Ports list:

Virtual Port Number (Point Index)	Name	Event Class Assigned (1, 2, 3 or none)	Description
-----------------------------------	------	--	-------------

5.10 Definition of Data Set Prototypes:

List of all data set prototypes. The following table is repeated for each Data Set Prototype defined.

Note: the number of data set prototypes known to the device are available remotely using object Group 0 Variations 212 and 213.

- Fixed, list shown in table below
- Configurable (current list may be shown in table below)
- Other, explain:

5.11 Definition of Data Set Descriptors:

List of all data set descriptors. The following table is repeated for each Data Set Descriptor defined.

Note: the number of data sets known to the device are available remotely using object Group 0 Variations 214 and 215.

- Fixed, list shown in table below
- Configurable (current list may be shown in table below)
- Other, explain:

5.12 Data Set Descriptors - Point Index Attributes

The following table is optional and correlates data set elements to point indexes of standard DNP3 Data Objects. The element number below refers to the position in the present value object (object 87) or event (object 88) data set and will not match the element number in the data set descriptor or data set prototype tables above.

----- End of Device Profile for Reference Device -----

----- End of Complete Device Profile -----